

INSTALLATION INSTRUCTIONS

**HIGH EFFICIENCY
SPLIT SYSTEM AIR CONDITIONER
AND HEAT PUMP COIL ONLY
INDOOR SECTION**

FOR USE WITH:

**OIL
GAS
FURNACES**

COPYRIGHT FEBRUARY, 1989
BARD MANUFACTURING COMPANY
BRYAN, OHIO

TABLE OF CONTENTS

| | | |
|-----|---|----|
| I. | Application and Location | 1 |
| | General | 1 |
| | Application | 3 |
| | Expansion Device | 4 |
| | Caution When Using 5780 Series Couplings | 5 |
| | Airflow Pressure Drop Measurement | 6 |
| | CFM for Add-On Coils | 6 |
| | Condensate Drain Drop | 8 |
| II. | Wiring | 9 |
| | General Operation Heat Pump/Fossil Fuel Furnace | 9 |
| | Note On Indoor Blower Operation | 9 |
| | Control Circuit Wiring--AC/HP | 9 |
| | Wall Thermostats AC/HP. | 10 |
| | Control Circuit Diagrams A/C. | 11 |
| | Control Circuit Diagrams H/P. | 12 |

FIGURES AND TABLES

| | |
|----------|---|
| Figure 1 | 1 |
| Figure 2 | 3 |
| Figure 3 | 3 |
| Figure 4 | 4 |
| Figure 5 | 5 |
| Figure 6 | 5 |
| Figure 7 | 6 |
| Figure 8 | 8 |

| | |
|---------|----|
| Table 1 | 1 |
| Table 2 | 2 |
| Table 3 | 7 |
| Table 4 | 9 |
| Table 5 | 10 |

APPLICATION AND LOCATION

GENERAL

The model A18AQ and S-A through A60AQ and S-A series indoor cooling coils are designed for use with outdoor section air conditioners and heat pumps. They are designed for use with gas or oil furnaces. Optional coil casing plenums are also available.

FIGURE 1
Nomenclature Explanation--Example:




TABLE 1

| COIL DIMENSIONS (Inches) | | | | |
|--------------------------|----|--------|--------|----------------------------|
| "A" Coil | A | B | C | Drain Pan Opening (W&L) |
| A18A* | 18 | 20-1/2 | 11-1/4 | 12-1/4 & 15-1/4 |
| A30A* | 18 | 20-1/2 | 14 | 12-1/4 & 15-1/4 |
| A36A* | 18 | 20-1/2 | 16 | 12-1/4 & 15-1/4 |
| A42A* | 22 | 20-1/2 | 18 | 14-3/4 & 15-1/4 |
| A48A* | 22 | 20-1/2 | 22 | 14-3/4 & 15-1/4 |
| A60A* | 25 | 20-1/2 | 24 | 16 x 15-1/4 |

TABLE 2

| APPROVED MATCHED COMBINATIONS, RATED CFM STATIC PRESSURE DROP, ORIFICE PART NUMBER AND DIAMETER 1 | | | | | | |
|--|------------------------------------|------|---------------------------------------|-------------------------------|---------------------|---------------------------|
| Condensing Unit Model Number | Evaporator Coil Model Number | CFM | Rated Airflow | Recommended Air Flow Range | Orifice Part No. | Orifice Diameter (In.) |
| | | | Pressure Drop "H ₂ O" 2 | | | |
| 24UACQB 24UACSB | A18AQ-A | 750 | .20 | 640 - 825 | 5625-059 (3) | .059 |
| | A18AS-A | | | | | |
| | A30AQ-B | 825 | .15 | 700 - 910 | 5625-059 (3) | .059 |
| | A30AQ-A A30AS-A | 825 | .15 | 700 - 910 | 5625-059 (4) | .059 |
| 30UACQA 30UACSA | A30AQ-A A30AS-A | 1000 | .20 | 850 - 1100 | 5625-063 (3) | .063 |
| 36UACQA 36UACSA 36UACSA-B | A30AQ-A A30AS-A | 1125 | .30 | 950 - 1240 | 5625-069 (4) | .069 |
| | A36AQ-A | 1200 | .30 | 1020 - 1320 | 5625-072 (3) | .072 |
| | A36AQ-A | 1200 | .30 | 1020 - 1320 | 5625-069 (4) | .069 |
| | A36AS-A | | | | | |
| | A42AQ-A A42AS-A | 1380 | .30 | 1170 - 1520 | 5625-069 (4) | .069 |
| 42UACQA 42UACSA | A48AQ-A A48AS-A | 1450 | .27 | 1230 - 1600 | 5625-069 (4) | .069 |
| | A42AQ-A A42AS-A | 1325 | .30 | 1125 - 1450 | 5625-078 (3) | .078 |
| 42UACSA-B | A48AQ-A A48AS-A | 1525 | .30 | 1300 - 1675 | 5625-078 (4) | .078 |
| 48UACQA 48UACSA | A42AQ-A A42AS-A | 1325 | .30 | 1125 - 1450 | 5625-081 (4) | .081 |
| 48UACSA-B | A48AQ-A A48AS-A | 1525 | .30 | 1300 - 1675 | 5625-081 (3) | .081 |
| 60UACQA 60UACSA | A48AS-A A48AS-A | 1500 | .30 | 1275 - 1650 | 5625-092 (4) | .092 |
| 60UACSA-B | A60AQ-A A60AS-A | 1900 | .30 | 1615 - 2100 | 5625-092 (3) | .092 |
| 18HPC6 | A30AQ-A | 650 | .10 | 550 - 700 | 5625-061 (5) | .061 |
| 24HPC6 | A30AQ-A | 750 | .15 | 650 - 825 | 5625-063 (3) | .063 |
| 36HPC7 | A36AQ-A | 1200 | .30 | 1020 - 1320 | 5625-067 (3) | .067 |
| 30HPC6 | A36AQ-A | 1130 | .26 | 950 - 1240 | 5625-067 (3) | .067 |
| 37BCS1 | A36AS-A | 1200 | .30 | 1020 - 1320 | 5625-069 (5) | .069 |
| 42BCS1 | A42AS-A | 1450 | .30 | 1230 - 1600 | 5625-078 (3) | .078 |
| | A48AS-A | 1450 | .25 | 1230 - 1600 | 5625-078 (5) | .078 |
| 48BCS2 | A48AS-A | 1500 | .25 | 1275 - 1650 | 5625-081 (3) | .081 |
| 60BCS1 | A60AS-A | 1900 | .30 | 1615 - 2100 | 5625-092 (3) | .092 |
| 24URPQA | A30AQ-A | 800 | .16 | 700 - 910 | 5625-059 (4) | .059 |
| 24URPQA | A30AQ-B | 800 | .16 | 700 - 910 | 5625-059 (3) | .059 |
| 30URPQA | A36AQ-A | 1050 | .20 | 900 - 1150 | 5625-067 (3) | .067 |
| 30URPQA | A42AS-A | 1050 | .15 | 900 - 1150 | 5625-067 (4) | .067 |
| 36URPQA | A36AQ-A | 1200 | .30 | 1020 - 1320 | 5625-072 (4) | .072 |
| 36URPQA | A36AQ-B | 1200 | .30 | 1020 - 1320 | 5625-072 (3) | .072 |
| 36URPQA | A42AS-A | 1200 | .20 | 1020 - 1320 | 5625-072 (4) | .072 |

IMPORTANT INSTALLER NOTE:

- (1) All coils are suitable for up or down airflow direction.
- (2) Measured across the evaporator coil assembly, including drain pan.
- (3) This orifice is shipped installed in the coil. When this combination of condensing unit and indoor coil is used, the orifice is properly sized.
- (4) Proper diameter orifice is NOT installed in the indoor coil. Proper orifice diameter is shipped with the outdoor unit packaged with its installation instructions. The orifice MUST be replaced with the proper orifice shown.
- (5) Proper diameter is NOT installed in indoor coil. Proper orifice diameter must be ordered separately. The orifice MUST be replaced with proper orifice shown.

APPLICATION

FIGURE 2
TYPICAL APPLICATION OF
COIL TO HIGHBOY FURNACE





FIGURE 3
TYPICAL APPLICATION OF COIL
COUNTERFLOW FURNACE



Every coil must have the required two inch minimum clearance between furnace heater exchanger and bottom of coil (Figure 2, dimension A), and not exceed a maximum of two inches between the top of coil and bottom of horizontal ductwork (Figure 2, dimension B).

When the ductwork takes off from only one side of the plenum, the minimum distance from top of coil to top of plenum is six inches (Figure 2, dimension C).

A duct should never be located between the coil and the source of air supply. If your coil is larger than the top of your furnace, a transition is required with a minimum of three inches.

CAUTION: Be sure to seal area on all sides between coil drain pan and plenum to prevent air from bypassing coil.

It is important to provide a removable access door in the plenum slightly larger than the coil for servicing or cleaning the coil.

EXPANSION DEVICE


The flow control orifice provides the function of the expansion device as well as distributes the refrigerant equally to all evaporator circuits. It features a "take apart" brass body which houses a removable piston-orifice assembly which meters the proper amount of refrigerant flow and serves as the expansion device. This orifice can be removed and replaced.

There is an orifice shipped installed with the flow control in each coil. Refer to Table 2 to find if the orifice shipped installed is matched to the outdoor unit. Example: Outdoor unit 30UACQA with A30AQ-A is a matched combination. For other combinations of indoor coil to outdoor unit application, the orifice in the flow control device **MUST** be changed to the size shown in the chart on Table 2. An additional proper sized orifice to be used with each outdoor unit is shipped packaged in the envelop with the installation instructions, with each outdoor unit. The installer should mark the size of the orifice installed on the rating plate of the indoor coil. The diameter of the orifice is stamped on the side of the brass orifice and on the plastic bag. Example: O63 indicates the orifice is .063" inside diameter.

CAUTION: Be sure there is no dirt introduced into the distributor--orifice assembly. Be sure and install the orifice with the bullet nose pointing in the proper direction as shown in Figure 4. Failure to do so will result in improper operation.

NOTE: If the orifice does not have to be changed, skip the instructions outlined further in Figure 4 and proceed to Figures 5 or 6 as applicable.

FIGURE 4
FLOW CONTROL ASSEMBLY
FIELD RESTRICTOR REPLACEMENT INSTRUCTIONS



NOTE: DO NOT CONNECT LINE SETS! If restrictor needs to be changed, change out restrictor first.

STEP 1 Remove charge/pressure from indoor unit (if necessary--coupling style).

STEP 2 Disassemble Flow Control Assembly by turning body hex.

STEP 3 If existing restrictor has not dropped out of the body when disassembled, remove by using a pin or paper clip. Discard this original restrictor.

STEP 4 Insert properly sized restrictor fully into the flow control body with rounded "bullet" nose towards the unit as shown. Insure the restrictor stays inserted in body before connecting mating half. See Table 2 for proper size.

STEP 5 Thread assembly halves together by hand to insure proper mating of threads and tighten until bodies "bottom" or a definite resistance is felt.


STEP 6 Using a marker pen or ink pen, mark a line lengthwise from the union nut to the bulkhead. Then tighten an additional 1/6 turn (or 1 hex flat). The misalignment of the line will show the amount the assembly has been tightened. This final 1/6 turn is necessary to insure the formation of the leakproof joint.

STEP 7 Complete piping and installation of unit per installation instructions. See Figure 5 for detailed assembly instructions for sweat type and Figure 6 for detailed assembly instructions for coupling type coils.

CAUTION WHEN USING 5780 SERIES COUPLINGS

If coupling is every disconnected, the Flow Control Assembly connection may also be loosened. If this should occur, care must be taken to avoid loss of the restrictor. If loosened, repeat Step 5 above to insure the reformation of leakproof joint.

FIGURE 5
FLOW CONTROL FIELD ASSEMBLY PROCEDURES
SWEAT STYLE LINE SET



STEP 8 Route the suction and liquid lines between the indoor and outdoor units.

STEP 9 The tubing should be cut square. Make sure it is round and free of burrs at the connecting ends, clean the tubing to prevent contaminants from entering the system.


STEP 10 Wrap a wet rag around the union nut of the flow control assembly.

STEP 11 Sparingly apply paste flux to the copper tube and insert into stub. Excessive or liquid flux can run inside assembly and cause corrosion. No flux is necessary if a low or zero silver braze alloy is used.

STEP 12 After brazing, quench with a wet rag to cool the joint and remove any flux residue.

STEP 13 Evacuate the lines and indoor coil before opening the base valves. Refer to instructions packed with the outdoor unit for details on setting the proper refrigerant charge.

FIGURE 6
FLOW CONTROL FIELD ASSEMBLY PROCEDURES
PRECHARGE COUPLING LINE SET




- STEP 8 Route the suction and liquid line between the indoor and outdoor unit. CAUTION: Do NOT connect the tubing to the outdoor unit yet.
- STEP 9 Remove protector caps and plugs.
- STEP 10 If necessary, carefully wipe coupling seats and threaded surfaces with a clean cloth to prevent the inclusion of dirt or any foreign material in the system.
- STEP 11 LUBRICATE male half diaphragm and synthetic rubber seal with refrigerant oil. Thread coupling halves together by hand to insure proper mating of threads. Use proper size wrenches (on line set coupling body hex and on union nut) and tighten until coupling bodies "bottom" or a definite resistance is felt.
- STEP 12 Using a marker or ink pen, mark a line lengthwise from the coupling union nut to the bulkhead. Then tighten an additional 1/4 turn; the misalignment of the line will show the amount the coupling has been tightened. This final 1/4 turn is necessary to insure the formation of leakproof joint. If a torque wrench is used, torque values recommends 10 to 12 foot pounds.
- STEP 13 Evacuate the lines and indoor unit before connecting to the outdoor unit. Refer to the installation instructions packed with the outdoor unit for details on setting the proper refrigerant charge. NOTE: The lines and indoor coil do not have to be evacuated if they were not opened to the atmosphere to change the orifice.

AIRFLOW PRESSURE DROP MEASUREMENT

A manometer or air draft gauge is required to check the air pressure drop across the indoor evaporator coil section.

The pressure (or positive) side of the gauge should connect to the air inlet (entering) side of the coil, and the suction (or negative) side of the gauge to the downstream (leaving) side of the coil. See Figure 7.

FIGURE 7
AIR DRAFT GAUGE OR MANOMETER



CFM FOR ADD-ON COILS

The furnace that you are going to add a heat pump to must be able to deliver enough air to satisfy the airflow listed in Table 2 for the coil being used.

In a heat pump application, the indoor coil becomes the condensing coil, this is why the amount of air is so critical. Not enough air results in too high of high side pressures and temperatures. The furnace CFM can be calculated by using the following formula:

$$\text{CFM} = \frac{\text{Output (BTU/H)}}{1.08 \times \text{Temp. Rise}}$$

When adding a coil to an existing GAS FURNACE, proceed as follows to determine the gas input to the furnace. Shut off all other gas appliances in the home, then set the indoor wall thermostat to call for heat. Go to the gas meter and clock the fastest moving dial, then refer to the chart below.

EXAMPLE: Most gas utilities use 1000 BTU per cubic foot of gas. If you were to clock the one cubic foot dial and found it took 36 seconds for one revolution, then in one hour the furnace would use 100,000 BTU, but we all know that no furnace is 100 percent efficient, so suppose we assume this furnace to be 70 percent efficient, then we should have approximately 70,000 BTU per hour output. Using the figure our formula would look like this:

$$\text{CFM} = \frac{70,000}{1.08 \times \text{T.R}} \quad \text{or} \quad \text{CFM} = \frac{70,000}{1.08 \times ?}$$

We must still obtain a temperature rise through the furnace. This is done by measuring the return air temperature and the supply air temperature. Let's again assume we were able to measure a 60 degree F temperature rise through the furnace. Now we can complete our formula.

$$\text{CFM} = \frac{70,000}{1.08 \times 60} \quad \text{or} \quad \text{CFM} = 65$$

Then, our CFM for this furnace would be 1076 CFM.

TABLE 3

| Seconds For One Rev. | SIZE OF TEST DIAL | | | | | Seconds For One Rev. | SIZE OF TEST DIAL | | | | |
|----------------------------|-------------------|----------------|--------------|--------------|--------------|----------------------------|-------------------|----------------|--------------|--------------|--------------|
| | 1/4 Cu. Ft. | 1/2 Cu. Ft. | 1 Cu. Ft. | 2 Cu. Ft. | 5 Cu. Ft. | | 1/4 Cu. Ft. | 1/2 Cu. Ft. | 1 Cu. Ft. | 2 Cu. Ft. | 5 Cu. Ft. |
| 10 | 90 | 180 | 360 | 720 | 1800 | 36 | 25 | 50 | 100 | 200 | 500 |
| 11 | 82 | 164 | 327 | 655 | 1636 | 37 | -- | -- | 97 | 195 | 486 |
| 12 | 75 | 150 | 300 | 600 | 1500 | 38 | 23 | 47 | 95 | 189 | 474 |
| 13 | 69 | 138 | 277 | 555 | 1385 | 39 | -- | -- | 92 | 185 | 462 |
| 14 | 64 | 129 | 257 | 514 | 1286 | 40 | 22 | 45 | 90 | 180 | 450 |
| 15 | 60 | 120 | 240 | 480 | 1200 | 41 | -- | -- | -- | 176 | 439 |
| 16 | 56 | 113 | 225 | 450 | 1125 | 42 | 21 | 43 | 86 | 172 | 429 |
| 17 | 53 | 106 | 212 | 424 | 1059 | 43 | -- | -- | -- | 167 | 419 |
| 18 | 50 | 100 | 200 | 400 | 1000 | 44 | -- | 41 | 82 | 164 | 409 |
| 19 | 47 | 95 | 189 | 379 | 947 | 45 | 20 | 40 | 80 | 160 | 400 |
| 20 | 45 | 90 | 180 | 360 | 900 | 46 | -- | -- | 78 | 157 | 391 |
| 21 | 43 | 86 | 171 | 343 | 857 | 47 | 19 | 38 | 76 | 153 | 383 |
| 22 | 41 | 82 | 164 | 327 | 818 | 48 | -- | -- | 75 | 150 | 375 |
| 23 | 39 | 78 | 157 | 313 | 783 | 49 | -- | -- | -- | 147 | 367 |
| 24 | 37 | 75 | 150 | 300 | 750 | 50 | 18 | 36 | 72 | 144 | 360 |
| 25 | 36 | 72 | 144 | 288 | 720 | 51 | -- | -- | -- | 141 | 355 |
| 26 | 34 | 69 | 138 | 277 | 692 | 52 | -- | -- | 69 | 138 | 346 |
| 27 | 33 | 67 | 133 | 267 | 667 | 53 | 17 | 34 | -- | 136 | 340 |
| 28 | 32 | 64 | 129 | 257 | 643 | 54 | -- | -- | 67 | 133 | 333 |
| 29 | 31 | 62 | 124 | 248 | 621 | 55 | -- | -- | -- | 131 | 327 |
| 30 | 30 | 60 | 120 | 240 | 600 | 56 | 16 | 32 | 64 | 129 | 321 |
| 31 | -- | -- | 116 | 232 | 581 | 57 | -- | -- | -- | 126 | 316 |
| 32 | 28 | 56 | 113 | 225 | 563 | 58 | -- | 31 | 62 | 124 | 310 |
| 33 | -- | -- | 109 | 218 | 545 | 59 | -- | -- | -- | 122 | 305 |
| 34 | 26 | 53 | 106 | 212 | 529 | 60 | 15 | 30 | 60 | 120 | 300 |
| 35 | -- | -- | 103 | 206 | 514 | | | | | | |

If the furnace is equipped with a direct drive motor, make sure you have it wired to high speed tap. If it is a belt drive motor, then read the motor's nameplate amp. Then hook on an amp probe and see if it is possible to speed the blower up by adjusting the variable pulley.

If you are at the limits of the motor, then check with the furnace manufacturer to see if a larger horsepower motor can be installed and also if the blower will give you the needed CFM with a larger motor.

When you have determined that your furnace can handle the required CFM for your coil, the indoor coil must be installed and your CFM calculation must be rechecked with the coil in place.

When adding to an OIL FURNACE, you must determine what size nozzle the unit has in the burner and then install a pressure gauge in the oil delivery pumps discharge port and set the pressure at 100 psig. An example might be that we find the burner equipped with a one gallon per hour nozzle, operating at 100 psi. This nozzle will deliver one G.P.H. and a gallon of No. 2 fuel oil has approximately 140,000 BTU of heat.

The 140,000 BTU is our input and again let us assume that this furnace is operating at 70 percent efficiency. Then our BTU output is 98,000 BTU, and if we use the rule of thumb that an oil furnace should operate with an 85 degree F temperature rise, then our formula would look like this:

$$\text{CFM} = \frac{98,000 \text{ BTU/H}}{1.08 \times 85 \text{ degree F}} \quad \text{or} \quad \frac{98,000 \text{ BTU/H}}{92} = 1065 \text{ CFM}$$

When adding on to an electric furnace, we must also take one more thing into consideration and that is the heat pump coil must be installed on the return side of the electric furnace. To find out what CFM the electric furnace can deliver, we must measure the voltage and amperage of each heating element or Volts x Amp = Watts. The total Watts x 3.4 BTU = BTU Output. An example might look like this with a 15kw electric furnace.

$$\begin{aligned} 240 \text{ Volts} \times 21 \text{ Amps} &= 5,040 \text{ Watts} \\ 5,040 \text{ Watts} \times 3 \text{ Elements} &= 15,120 \text{ Watts} \\ 15,120 \text{ Watts} \times 3.4 \text{ BTU/Watt} &= 51,408 \text{ BTU} \end{aligned}$$

One word of caution, never go by nameplate rating. Always measure volts and amps.


One more item that is different with an electric furnace and that is, never obtain a supply air temperature reading in sight of the electric element (because of the radiant affect). Now our formula looks like this again:

$$\text{CFM} = \frac{51408 \text{ BTU/H}}{1.08 \times 44 \text{ degree F}} \quad \text{or} \quad \frac{51408 \text{ BTU/H}}{48} = 1071 \text{ CFM}$$

CONDENSATE DRAIN TRAP

It is very important to provide a trap in the condensate drain line to allow a positive liquid seal in the line and assure correct drainage from the coil condensate pan.

Install condensate drain trap shown below. Use drain connection size or larger. Do not operate unit without trap. Unit must be level or slightly inclined toward drain.



II. WIRING

GENERAL OPERATION--HEAT PUMP/FOSSIL FUEL FURNACE

This type of system is a one-stage heating system, even though a two-stage heat wall thermostat is used. The thermostats specified for use are special thermostats for heat pumps with extra switches, signal lights, and special circuitry for heat pumps, and by design are two-stage heating thermostats. Since the extra features are also required for the special heat pump/fossil fuel systems, the same thermostats are used, but the second stage circuit is not used. This is further explained in the next paragraph.

While it would be possible to electrically connect the furnace to the second stage of the thermostat, the heat pump coil is located downstream from the furnace heat exchanger, and continuous simultaneous operation of the furnace and heat pump will result in excessive high discharge pressures and temperatures at the compressor and resultant overload tripping problems. For this reason, the control circuit wiring diagrams shown later in this manual will not allow the furnace to operate except during defrost cycles unless an outdoor thermostat is added to the circuit. The addition of an outdoor thermostat used as a changeover thermostat will switch the system from heat pump heating to furnace heating based on the outdoor temperature. At no time will continuous operation of the heat pump and furnace be allowed.

An outdoor thermostat is used as a changeover thermostat, properly set to control at or just above the balance point, will allow the most economical operation of the system. The changeover (outdoor) thermostat switches off the heat pump and on the fossil fueled furnace, based on the outdoor temperature. There is a 5 degree F differential in the changeover (outdoor) thermostat, so when the heat pump is de-energized and the furnace is activated, the outdoor temperature must rise 5 degrees F above the set-point of the thermostat to stop the furnace and start the heat pump again. NOTE: See manual 2100-057 "Heat Pump Sizing" for procedure to determine correct balance point.

The emergency heat switch allows for manual cutoff of the heat pump and operation of the furnace at any outdoor temperature.

NOTE ON INDOOR BLOWER OPERATION

Because of the design of the heat pump wall thermostats, and the fact that a cooling blower relay is installed in parallel with the fan side of the combination fan/limit control found on most gas or oil furnaces, the furnace blower will start as soon as the wall thermostat calls for heat. This is required for the heat pump and will also occur during the time when the heat pump is off and the furnace is operating. This is contrary to normal blower operation on a gas or oil furnace and is sometimes misunderstood, but an inherent part of the system operation. While in the gas or oil furnace mode of operation, there will still be a run-on in blower operation until the bonnet temperature cools down to the blower off setting of the fan/limit switch.

CONTROL CIRCUIT WIRING

There are two (2) separate control diagrams for fossil fuel furnaces with heat pumps, and two (2) control diagrams for fossil fuel furnaces with air conditioning.

TABLE 4

| Air Conditioning System | Gas Furnace Control Diagram | Oil Furnace Control Diagram |
|-------------------------|-----------------------------|-----------------------------|
| All | 4091-100 | 4091-101 |

TABLE 5

| Heat pump system | Gas furnace control diagram | Oil furnace control diagram |
|---|-----------------------------|-----------------------------|
| 18HPQ 24UHPQA 24HPQ 30UHPQA 30HPQ 36UHPQA 36HPQ | 4091-200 | 4091-201 |
| 42HPQ 60HPQ 48HPQ | 4091-202 | 4091-203 |


WALL THERMOSTATS

The following wall thermostats and subbases should be used as indicated, depending on the application.

TABLE 6

| AIR CONDITIONING THERMOSTATS | | |
|------------------------------|-----------|--|
| Part No. | Model No. | Description |
| 8403-002 | T87F3111 | THERMOSTAT--1 stg. heat, adj. heater, Mercury |
| 8404-003 | Q539A1220 | SUBBASE --System Heat-Off-Cool Fan: On-Auto |
| 8403-008 | ID51-605 | THERMOSTAT--1 stg. cool, System w/Off Sw. Snap Action Fan: Auto-On |
| 8403-009 | IF56-318 | THERMOSTAT--1 st. cool, 1 stg. heat, Adj. heater Mercury System: Heat-Off-Cool Fan: Auto-On |
| 8403-019 | T874C1000 | THERMOSTAT--1 stg. cool, 2 stg. heat, Adj. heater, Mercury |
| 8404-012 | Q674A1001 | SUBBASE --System: Heat-Auto-Cool Fan: Auto-On |
| HEAT PUMP THERMOSTATS | | |
| Part No. | Model No. | Description |
| 8403-017 | T874R1129 | THERMOSTAT--1 stg. cool, 2 stg. heat, 1st stage fixed, 2nd stg. adj. heat anticipators |
| 8404-009 | Q674L1181 | SUBBASE --System switch: Em. Heat-Heat-Off-Cool Fan switch: On-Auto SPECIAL FEATURE: Manual Changeover (Non-Cycling Rev. Valve) Em. heat light and System check light |
| 8403-018 | T874N1024 | THERMOSTAT--1 stg. cool, 2 stg. heat, 1st stage fixed, 2nd stg. adj., heat anticipators |
| 8404-010 | Q674F1261 | SUBBASE --System switch: Off-Cool-Auto-Heat-Em.Ht. Fan switch: On-Auto SPECIAL FEATURE: Auto system changeover, Em. heat light and System check light |
| 8403-024 | IF58-45 | THERMOSTAT--1 stg. cool, 2 stg. heat, 1st stage fixed, 2nd stg. adj. heater System switch: Em. Heat-Heat-Off-Cool Fan Switch: On-Auto |

WARNING: Only the thermostats and subbases listed in Table 6 have been approved for use with the 24UEPQA, 30UEPQA, and 36UEPQA models. Use of any other thermostat/subbase combination can cause a condition of no blower operation during defrost cycle when auxiliary heat is energized causing an unsafe condition and possible fire.




△ SET ADJUST HEAT ANTICIPATION (SEE FURNACE INSTALLATION INSTRUCTIONS)
 △ INSTALL JUMPER R-R
 △ IF THE FURNACE IS NOT INTERNALLY WIRED FOR AOD ON AIR CONDITIONING, A FAN CENTER WILL NEED TO BE ADDED.

| | |
|----------------|--------------|
| FACTORY WIRING | FIELD WIRING |
| LOW VOLTAGE | --- |
| HIGH VOLTAGE | --- |

AIR CONDITIONER VS GAS FURNACE

4091-100




△ SET ADJUST HEAT ANTICIPATION (SEE FURNACE INSTALLATION INSTRUCTIONS)
 △ IF THE FURNACE IS NOT INTERNALLY WIRED FOR AOD ON AIR CONDITIONING, A FAN CENTER WILL NEED TO BE ADDED.

| | |
|----------------|--------------|
| FACTORY WIRING | FIELD WIRING |
| LOW VOLTAGE | --- |
| HIGH VOLTAGE | --- |

AIR CONDITIONER VS OIL FURNACE

4091-101



△ SET ADJUST HEAT ANTICIPATION (SEE FURNACE INSTALLATION INSTRUCTIONS)

△ WHEN OUTDOOR THERMOSTAT (USED AS CHANGEOVER THERMOSTAT) IS INSTALLED, REMOVE JUMPER Y-11.

△ IF IT DESIRED NOT TO ALLOW FURNACE TO CYCLE "ON" DURING DEEFROST, A 24V FACTORY WIRE RETURN (TERMINAL "3" OF DEFROST RELAY AND TERMINAL "4" ON EMERGENCY HEAT RELAY ON HPU MODELS OR TERMINAL "2" OF HEATPUMP CONTROL AND TERMINAL "3" ON TERMINAL BOARD ON LPP MODELS) MUST BE REMOVED.

△ HPU SERIES MODEL DO NOT HAVE ④ TERMINAL AND IT IS NOT REQUIRED TO RUN ④ WIRE TO THESE MODELS.


△ LOCATE ISOLATING RELAY IN OIL FURNACE. NECESSARY TO SEPARATE 24V POWER SUPPLY OF HEATPUMP FROM 24V POWER SUPPLY BUILT INTO OIL BURNER PRIMARY CONTROL.

△ IF THE FURNACE IS NOT INTERNALLY WIRED FOR ADD ON AIR CONDITIONING, A FAM CENTER WILL NEED TO BE ADDED.

| | |
|----------------|--------------|
| FACTORY WIRING | FIELD WIRING |
| LOW VOLTAGE | HIGH VOLTAGE |

HEAT PUMP WITH ELECTRIC FURNACE

4091-200



△ SET ADJUST HEAT ANTICIPATION (SEE FURNACE INSTALLATION INSTRUCTIONS)

△ WHEN OUTDOOR THERMOSTAT (USED AS CHANGEOVER THERMOSTAT) IS INSTALLED, REMOVE JUMPER Y-11.

△ IF IT DESIRED NOT TO ALLOW FURNACE TO CYCLE "ON" DURING DEEFROST, A 24V FACTORY WIRE RETURN (TERMINAL "3" OF DEFROST RELAY AND TERMINAL "4" ON EMERGENCY HEAT RELAY ON HPU MODELS OR TERMINAL "2" OF HEATPUMP CONTROL AND TERMINAL "3" ON TERMINAL BOARD ON LPP MODELS) MUST BE REMOVED.

△ HPU SERIES MODEL DO NOT HAVE ④ TERMINAL AND IT IS NOT REQUIRED TO RUN ④ WIRE TO THESE MODELS.

△ LOCATE ISOLATING RELAY IN OIL FURNACE. NECESSARY TO SEPARATE 24V POWER SUPPLY OF HEATPUMP FROM 24V POWER SUPPLY BUILT INTO OIL BURNER PRIMARY CONTROL.

△ IF THE FURNACE IS NOT INTERNALLY WIRED FOR ADD ON AIR CONDITIONING, A FAM CENTER WILL NEED TO BE ADDED.

| | |
|----------------|--------------|
| FACTORY WIRING | FIELD WIRING |
| LOW VOLTAGE | HIGH VOLTAGE |

HEAT PUMP WITH OIL FURNACE

4091-201