

INSTALLATION INSTRUCTIONS

MODULAR MASTER
WALL MOUNTED
PACKAGE HEAT PUMPS

MODELS

MHP30A

MHP36A


)

,

)

4


)



If fresh air is required, an optional fresh air assembly (8620-020) must be ordered separately.

Nomenclature Explanation

Example:



MODEL	MHP30A-A00	MHP30A-A05	MHP30A-A10	MHP36A-A00	MHP36A-A05	MHP36A-A10
Cooling Capacity Btuh	28,000	28,000	28,000	33,600	33,600	33,600
Hi Temperature Htg. Btuh (47°)	30,600	30,600	30,600	36,000	36,000	36,000
Supplemental Heat Strip Kw	None	5	10	None	5	10
Supplemental Heat Strip Btuh	--	17065/12800	34130/25600	--	17065/12800	34130/25600
Electrical Rating — 60 Hz	230/208-1	230/208-1	230/208-1	230/208-1	230/208-1	230/208-1
Operating Voltage Range	197-253	197-253	197-253	197-253	197-253	197-253
Minimum Circuit Ampacity	25	51	77	31	57	83
No. Field Power Ckts.	1	1	1	1	1	1
**Field Wire Size	#10	#6	#3	#8	#4	#3
Ground Wire Size	#10	#10	#8	#10	#10	#8
***Req'd Max. External Fuses	40	60	80*	50	60	90*
Total Unit Amps 240/208	18.3/20.8	39.1/38.9	59.9/57.0	23.3/25.8	44.1/43.9	64.9/62
Internal Fuses (Standard)	None	None	60/30	None	None	60/30
Internal Circuit Breakers (Option C)	40	60	60,30	50	60	60,30
Compressor — Circuit A						
Volts		230/208			230/208	
Rated Load Amps 230/208		13/15.5			18/20.5	
Branch Circuit Selection Current		15.5			20.5	
Lock Rotor Amps		76/76			97/97	
Fan Motor & Condenser						
Fan Motor — HP/RPM		1/5/1050			1/5/1050	
Fan Motor — AMPS		1.4			1.4	
Fan Motor — DIA/CFM		20"/1800			20"/1800	
Face Area Sq.Ft./Row/Fins per in.		4.7/2/12			4.7/2/12	
Motor and Evaporator						
Blower Motor — HP/RPM		1/2/1600			1/2/1600	
Blower Motor — AMPS		3.9			3.9	
CFM Cooling & E.S.P. w/Filter (Rated) (Hi)		1000/.30			1060/.15	
Face Area Sq.Ft./Row/Fins per in.		2.7			2.7	
Filter Sizes (Inches)		14x25x1			14x25x1	
Refrigerant 22 — oz.		88			83	
Shipping Weight — lbs.		330			330	

*Sizes 70A or greater are not HACR type.

**60°C copper wire size.

***Maximum time delay fuse or HACR type circuit breaker.

IMPORTANT

The equipment covered in this manual is to be installed by trained, experienced service and installation technicians. Any heat pump is more critical of proper operating, charge and an adequate duct system than a straight air conditioning unit. All duct work supply and return, must be properly sized for the design air flow requirement of the equipment. ACCA is an excellent guide to proper sizing. All duct work or portions thereof not in the conditioned space should be properly insulated in order to both conserve energy and prevent condensation or moisture damage.

SHIPPING DAMAGE

Upon receipt of equipment, the carton should be checked for external signs of shipping damage. If damage is found, the receiving party must contact the last carrier immediately, preferably in writing, requesting inspection by the carrier's agent.

GENERAL

The refrigerant system is completely assembled and charged. All internal wiring is complete.

The unit is designed for use with or without duct work. Flanges are provided for attaching the supply and return ducts.

These instructions explain the recommended method to install the air cooled self-contained unit and the electrical wiring connections to the unit.

These instructions and any instructions packaged with any separate equipment required to make up the entire air conditioning system should be carefully read before beginning the installation. Note particularly "Starting Procedure" and any tags and/or labels attached to the equipment.

While these instructions are intended as a general recommended guide, they do not supersede any national and/or local codes in any way. Authorities having jurisdiction should be consulted before the installation is made.

INSTALLATION

Size of unit for a proposed installation should be based on heat loss calculation made according to methods of Air Conditioning Contractors of America (ACCA). The air duct should be installed in accordance with the Standards of the National Fire Protection Association for the Installation of Air Conditioning and Ventilating systems of Other Than Residence Type, NFPA No. 90A, and Residence Type Warm Air Heating and Air Conditioning Systems, NFPA No. 90B. Where local regulations are at a variance with instructions, installer should adhere to local codes.

DUCT WORK

Design the duct work according to methods given by the Air Conditioning Contractors of America. When duct runs through unheated spaces, it should be insulated with a minimum of one inch of insulation. Use insulation with a vapor barrier on the outside of the insulation. Flexible joints should be used to connect the duct work to the equipment in order to keep the noise transmission to a minimum.

A one-inch clearance to combustible material for the first three feet of duct attached to the outlet air frame is required. See page 5 for further details.

FILTER

A one inch throwaway filter is supplied with each unit. The filter slides into position making it easy to service. This filter can be serviced from the outside by removing the service door.

FRESH AIR INTAKE

All units are built with a fresh air inlet opening punched in the left unit side. This opening is covered by a factory installed blank off plate, model BOP20.

A fresh air damper assembly, model FAD20, may be ordered separately to accommodate the variety of state and local codes requiring fresh air capability.

All capacity, efficiency and cost of operation information as required for Department of Energy "EnergyGuide" fact sheets is based on the fresh air blank off plate being in place and is recommended for maximum energy efficiency.

WALL MOUNTING

1. Two holes, the size of the supply and return air openings must be cut through the wall as shown in Figure 1.
2. On wood-frame walls, the wall construction must be strong and rigid enough to carry the weight of the unit without transmitting any unit vibration.
3. Concrete block walls must be thoroughly inspected to insure that they are capable of carrying the weight of the installing unit.
4. Ducts through the walls must be insulated and all joints taped or sealed to prevent air or moisture entering the wall cavity.
5. Some installations may not require any return air duct. It is recommended that on this type of installation that a filter grille be located in the wall. Filters must be of sufficient size to allow a maximum velocity of 400 FPM.

NOTE: If no return air duct is used, applicable installation codes may limit this cabinet to installation only in a single story structure.

WIRING - MAIN POWER

Refer to the unit rating plate for wire sizing information and maximum fuse or "HACR Type" circuit breaker size. Each outdoor unit is marked with a "Minimum Circuit Ampacity." This means that the field wiring used must be sized to carry that amount of current. Depending on the installed Kw of electric heat, there may be two field power circuits required. If this is the case, the unit serial plate will so indicate. Some models are suitable only for connection with copper wire, while others can be wired with either copper or aluminum wire. Each unit and/or wiring diagram will be marked "Use Copper Conductors Only" or "Use Copper or Aluminum Conductors." These instructions MUST BE adhered to. Refer to the National Electrical Code for complete current carrying capacity data on the various insulation grades of wiring material.


The electrical data lists fuse and wire sizes (60°C copper) for all models, including the most commonly used heater sizes. Also shown are the number of field power circuits required for the various models with heaters.

Field conduit connections must be to the control box and not terminate at the cabinet.

The unit rating plate lists a "Maximum Time Delay Relay Fuse" or "HACR Type" circuit breaker that is to be used with the equipment. The correct size must be used for proper circuit protection and also to assure that there will be no nuisance tripping due to the momentary high starting current of the compressor motor.

WIRING - 24V CONTROL CIRCUIT

Seven (7) wires should be run from thermostat subbase to the 24V terminal board in the unit. An 18 gauge copper, color-coded thermostat cable is recommended. The connection points are shown on most of the wiring diagrams and are also shown below.



IMPORTANT NOTE: Only the thermostat and subbase combinations as shown above will work with this equipment. The stat and subbase **MUST** be matched, and correct operation can be assured only by proper selection and application of these parts.

CONDENSATE DRAIN

A plastic drain hose extends from the drain pan at the top of the unit down to the unit base. There are openings in the unit base for the drain hose to pass through. In the event the drain hose is connected to a drain system of some type, it must be an open or vented type system to assure proper drainage.

PRESSURE SERVICE PORTS

High and low pressure service ports are installed on all units so that the system operating pressures can be observed. Pressure curves can be found later in the manual covering all models on both cooling and heating cycles. It is imperative to match the correct pressure curve to the unit by model number.

SEQUENCE OF OPERATION

Cooling - Circuit R-Y makes at thermostat pulling in compressor contactor, starting the compressor and outdoor motor. The G (indoor motor) circuit is automatically completed on any call for cooling operation, or can be energized by manual fan switch on subbase for constant air circulation.

Heating - A 24V solenoid coil on reversing valve controls heating cycle operation. Two thermostat options, one allowing "Auto" changeover from cycle to cycle and the other constantly energizing solenoid coil during heating season and thus eliminating pressure equalization noise except during defrost, are to be used. On "Auto" option, a circuit is completed from R-W1 and R-Y on each heating "on" cycle, energizing reversing valve solenoid and pulling in compressor contactor starting compressor and outdoor motor. R-G also make starting indoor blower motor. Heat pump heating cycle now in operation. The second option has no "Auto" changeover position, but instead energizes the reversing valve solenoid constantly whenever the system switch on subbase is placed in "Heat" position, the "B" terminal being constantly energized from R. A thermostat demand for heat completes R-Y circuit, pulling in compressor contactor starting compressor and outdoor motor. R-G also make starting indoor blower motor.

COMPRESSOR CUT-OFF THERMOSTAT & OUTDOOR THERMOSTATS

Heat pump compressor operation at outdoor temperatures below 0°F are neither desirable nor advantageous in terms of efficiency. Since most equipment at time of manufacture is not designated for any specific destination of the country, and most of the equipment is installed in areas not approaching the lower outdoor temperature range, the compressor cut-offs are not factory installed.

Outdoor thermostats are available to hold off various banks of electric heat until needed as determined by outdoor temperature. The set point of either type of thermostat is variable with geographic region and sizing of the heating equipment to the structure. Utilization of the Heating Application Data and the heat loss calculation of the building are useful in determining the correct set points.

COMPRESSOR CUT-OFF AND OUTDOOR THERMOSTAT WIRING

See specific wiring information on page 6.

HEAT ANTICIPATION

Both of the thermostats shown below have a fixed heat anticipator for stage 1 with no adjustment required. Stage 2 has an adjustable anticipator for the W2 connection and fixed for the W3 connection. Both the W2 and W3 circuits are controlled by the stage 2 bulb. The only heat anticipator that needs to be checked is stage 2 and it should be set to match the load carried by the W2 circuit. The normal factory wiring provides for only one electric heat contactor to be controlled by W2, and the anticipator should be set at .40A. If special field wiring is done, it is best to actually measure the load but a good rule is .40A for each heat contactor controlled by W2.

WALL THERMOSTAT AND SUBBASE COMBINATIONS			
Group	Thermostat	Subbase	Predominant Feature
A	8403-017 (T874R1129)	8404-009 (Q674L1181)	Heat or Cool ① No Auto
B	8403-018 (T874N1024)	8404-010 (Q674F1261)	Automatic Heat-Cool Changeover Position ②

- ① No automatic changeover position--must manually place in heat or cool. Reversing valve remains energized at all times system switch is in heat position (except during defrost cycle). No pressure equalization noise when thermostat is satisfied on either heating or cooling.
- ② Allows thermostat to control both heating and cooling operation when set in "AUTO" position. Reversing valve de-energizes at end of each "ON" heating cycle.

IMPORTANT NOTE: Both thermostat and subbase combinations shown above incorporate the following features: Man-Auto fan switch, Off-Heat-Cool-Em. Heat Switch, and two (2) indicator lamps—one for emergency heat and one for compressor malfunction.

THERMOSTAT INDICATOR LAMP

The red lamp marked "EM.HT." comes on and stays on whenever the system switch is placed in the emergency heat position.

EMERGENCY HEAT POSITION

The operator of the equipment must manually place the system switch in this position. This is done when there is a known problem with the indoor section, or when the green "check" lamp comes on indicating a problem.

DEFROST CYCLE

The defrost cycle is controlled by time and temperature. The 24 volt timer motor runs all the time the compressor is in operation. When the outdoor temperature is in the lower 40°F temperature range or colder, the outdoor coil temperature is 32°F or below. This temperature is sensed by the defrost thermostat mounted near the bottom of the outdoor coil on a return bend. The defrost thermostat closes at approximately 32°F. Every 60 (or 30) minutes that the compressor is running, contacts 3-5 close for 7 minutes, with contacts 3-4 closed for the first 40 seconds of that 7 minutes. If the defrost thermostat is closed, the defrost relay energizes and places the system in defrost mode. An interlocking circuit is created with timer contacts 3-5 and defrost relay contacts 7-9 in series.


During the defrost mode, the refrigerant cycle switches back to the cooling cycle, the outdoor motor stops, electric heaters are energized, and hot gas passing through the outdoor coil melts any accumulated frost. When the temperature rises to approximately 57°F, the defrost thermostat opens, de-energizing the defrost relay and returning the system to heating operation.

If some abnormal or temporary condition such as a high wind causes the heat pump to have a prolonged defrost cycle, contacts 3-5 of the defrost timer will open after 7 minutes and restore the system to heating operations automatically.

There are two time settings on the defrost timer--30 minutes and 60 minutes. Most models are shipped wired on the 60 minute setting for greatest operating economy. If special circumstances require a change to the shorter time, remove wire connected to terminal 5/60 and reconnect to terminal 5/30.

There is a manual advance knob located on the timer. This can be used to advance timer to contact closure point if it is desired to check out defrost cycle operation, without waiting for time to elapse.

DEFROST TIMER WIRING



NOTE: All models are connected to 5/60 terminal (60 minute). Any model can be changed from 60 minutes to 30 minutes by unplugging from 5/60 terminal and reconnecting to 5/30 terminal as shown by dotted line.

SERVICE HINTS

1. Caution homeowner to maintain clean air filters at all times. Also, not to needlessly close off supply and return air registers. This reduces air flow through the system, which shortens equipment service life as well as increasing operating costs.
2. Switching to heating cycle at 75°F or higher outside temperature may cause a nuisance trip of the manual reset high pressure switch.
3. The heat pump wall thermostats perform multiple functions. Be sure that all function switches are correctly set for the desired operating mode before trying to diagnose any reported service problems.

4. Check all power fuses or circuit breakers to be sure that they are the correct rating.
5. Periodic cleaning of the outdoor coil to permit full and unrestricted airflow circulation is essential.

IMPORTANT INSTALLER NOTE

For improved start-up performance wash the indoor coil with a dishwasher detergent.

CRANKCASE HEATERS

All units are provided with some form of compressor crankcase heat. Some single phase units utilize the compressor motor start winding in series with a portion of the run capacitor to generate heat within the compressor shell to prevent liquid refrigerant migration.

Some three phase units utilize a wraparound type of crankcase heater that warms the compressor oil from the outside.

Some single and three phase models have an insertion well-type heater located in the lower section of the compressor housing. This is a self-regulating type heater that draws only enough power to maintain the compressor at a safe temperature.

Some form of crankcase heat is essential to prevent liquid refrigerant from migrating to the compressor, causing oil pump out on compressor start-up and possible valve failure due to compressing a liquid.

Refer to unit wiring diagram to find exact type of crankcase heater used.

The following decal is affixed to all outdoor units detailing start-up procedure. This is very important. Please read carefully.

IMPORTANT


THESE PROCEDURES MUST BE FOLLOWED AT INITIAL START-UP AND AT ANY TIME POWER HAS BEEN REMOVED FOR 12 HOURS OR LONGER.

TO PREVENT COMPRESSOR DAMAGE WHICH MAY RESULT FROM THE PRESENCE OF LIQUID REFRIGERANT IN THE COMPRESSOR CRANKCASE

1. MAKE CERTAIN THE ROOM THERMOSTAT IS IN THE "OFF" POSITION. (THE COMPRESSOR IS NOT TO OPERATE).
2. APPLY POWER BY CLOSING THE SYSTEM DISCONNECT SWITCH. THIS ENERGIZES THE COMPRESSOR HEATER WHICH EVAPORATES THE LIQUID REFRIGERANT IN THE CRANKCASE.
3. ALLOW 4 HOURS OR 60 MINUTES PER POUND OF REFRIGERANT IN THE SYSTEM AS NOTED ON THE UNIT RATING PLATE, WHICHEVER IS GREATER.
4. AFTER PROPERLY ELAPSED TIME THE THERMOSTAT MAY BE SET TO OPERATE THE COMPRESSOR.
5. EXCEPT AS REQUIRED FOR SAFETY WHILE SERVICING -- DO NOT OPEN SYSTEM DISCONNECT SWITCH.

7961 061

FIGURE 1.




MOUNTING INSTRUCTIONS

1. These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides and at the bottom.
2. The unit itself is suitable for "0" inch clearance, but the supply air duct flange and the first few feet of supply air duct require 1 inch clearance to combustible material. If combustible wall, use 30"x10" dimensions for sizing, if non-combustible, use 28"x8" dimensions.
3. After the wall opening positions have been selected, lay out the position for the bottom and side brackets. Fasten the brackets securely to the wall (type of fasteners will depend on wall construction).
4. Be sure to observe the 10" dimension when attaching the side brackets. This will assure that no screws are driven into the unit sides damaging any internal parts. One-half inch sheet metal screws are recommended.
5. For additional mounting rigidity, the return air and supply air (depending upon wall construction) frames or collars can be drilled and screwed or welded to the structural wall itself. Be sure to observe required clearance if combustible wall.
6. Maintain 30 inches minimum clearance on right side of unit to allow access to heat strip and control panel.

FAN BLADE SETTING DIMENSIONS

Shown in the drawing below are the correct fan blade setting dimensions for proper air delivery across the outdoor coil.

Any service work requiring removal or adjustment in the fan and/or motor area will require that the dimensions below be checked and blade adjusted in or out on the motor shaft accordingly.




MODEL	DIM. A
MHP30A	2-1/4
MHP36A	2-1/4

RATED CFM AND E.S.P. (WET COIL--COOLING)			
Model	Rated* CFM	Rated* E.S.P.	Recommended Airflow Range
MHP30A	1000	.22	850 - 1100
MHP36A	1060	.15	900 - 1160

*Rated CFM and E.S.P. on high speed tap.

COMPRESSOR CUT-OFF AND OUTDOOR THERMOSTAT WIRING



REFRIGERANT CHARGE

The correct system R-22 charge is shown on the unit rating plate. Optimum unit performance will occur with a refrigerant charge resulting in a suction line temperature (6" from compressor) as shown in the following table:


Model	Rated Airflow	95°F OD Temp.	82°F OD Temp.
MHP30A	1000	59 - 61	71 - 73
MHP36A	1060	50 - 52	63 - 65

The above suction line temperatures are based upon 80°F dry bulb/67°F wet bulb (50% R.H.) temperature and rated airflow across the evaporator during cooling cycle.

INDOOR BLOWER PERFORMANCE CFM--DRY COIL WITH FILTER		
E.S.P. Inches H ₂ O	Models MHP30A-MHP36A	
	Low	High
.0	950	1200
.1	910	1150
.2	875	1115
.3	--	1065
.4	--	1015
.5	--	965

PACKAGE HEAT PUMP MODEL MHP30A

3/87




Cooling curves are based upon 5000, 7000, 10,000, and rated CFM (airflow) across the evaporator coil and should be used for reference purposes only. Specific information can be found under section titled "Refrigerant Charge" elsewhere in manual. If there is any doubt as to correct operating charge being in the system, the charge should be removed, system evacuated, and recharged according to serial plate instructions. Heating curves are based on 70DB R.A. temperature.

LOW SIDE PRESSURE--PSIG
(SUCTION LINE)

PACKAGE HEAT PUMP MODEL MHP36A

3/87



... (airflow) across the evaporator coil and should be ...
 reference purposes only. Specific information can be found
 under section titled "Refrigerant Charge" elsewhere in manual.
 If there is any doubt as to correct operating charge being in the
 system, the charge should be removed, system evacuated, and
 recharged according to serial plate instructions. Heating curves
 are based on 1000 Btu/h temperature.


LOW SIDE PRESSURE--PSIG
 (SUCTION LINE)

PARTS LIST
Single Package Heat Pumps

4/87

Part No.	Description	MHP30A	MHP30A-A05	MHP30A-A10	MHP30A-A00/C	MHP30A-A05/C	MHP30A-A10/C	MHP36A	MHP36A-A05	MHP36A-A10	MHP36A-A00/C	MHP36A-A05/C	MHP36A-A10/C
5202-004	Accumulator	x	x	x	x	x	x	x	x	x	x	x	x
5811-001	Capillary Tube 25 x .050	4	4	4	4	4	4	x	x	x	x	x	x
5811-005	Capillary Tube 38 x .059	2	2	2	2	2	2	4	4	4	4	4	4
5811-036	Capillary Tube 28 x .059							2	2	2	2	2	2
8605-008	Crankcase Heater							x	x	x	x	x	x
8615-015	Circuit Breaker										1		
8615-014	Circuit Breaker				1								
8615-016	Circuit Breaker					1	1					1	1
8615-013	Circuit Breaker						1						1
4083-110	Wiring Diagram	x						x					
4083-111	Wiring Diagram				x						x		
4083-120	Wiring Diagram		x						x				
4083-121	Wiring Diagram					x				x		x	
4083-130	Wiring Diagram			x						x			
4083-131	Wiring Diagram						x						x

Supersedes all previous lists. Subject to change without notice.



T874N1024/
Q674F1261
or
T874R1129/
Q674F1181

24V Terminal Block

Fused Disconnect Switch




230/208-60-1

USE COPPER OR ALUMINUM WIRE

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----

⚠ For 208V operation move this wire to 208V transformer tap.

Chart A	
MODEL NO.	RUN CAP.
MHP30A	35/370
MHP36A	35/440



TB74M1024/
Q674FT261
OR
TB74R1129/
Q674F1181

24V Terminal
Block

Circuit
Breaker MHP30A : 40 A.
MHP36A : 50 A.


Equip.
Ground

USE COPPER OR
ALUMINUM WIRE

FACTORY WIRING FIELD WIRING
Low Voltage ———
High Voltage - - - - -

⚠ For 208V operation move this
wire to 208V transformer tap.

CHART A	
MODEL NO.	RUN CAP.
MHP30A	35/370
MHP36A	35/440



T874N1024/
Q674F1261
or
T874R1129/
Q674F1181

24V Terminal Block

FACTORY WIRING **FIELD WIRING**
 Low Voltage ————
 High Voltage - - - -

⚠ For 208V operation move this wire to 208V transformer tap.

USE COPPER OR ALUMINUM WIRE


CHART A	
MODEL NO.	RUN CAP.
MHP30A	35/370
MHP36A	35/440

Fused Disconnect Switch

230/208-60-1

4083-120 B

WIRED
T1



T874N1024/
Q674F1261
or
T874R1129/
Q674F1181

24V Terminal Block

	FACTORY WIRING	FIELD WIRING
Low Voltage	————	-----
High Voltage	-----	————

⚠ For 208V operation move this wire to 208V transformer tap.

USE COPPER OR ALUMINUM WIRE

CHART A	
MODEL NO.	RUN CAP.
MHP30A	35/370
MHP36A	35/440


230/208-60-1

4083-121 B

T874N1024/
Q674F1261

or

T874R1129/
Q674F1181



Compressor

Internal Overload

Immersion
Crankcase
Heater

See Chart A
Run Capacitor

Compressor
Contactor

T2 T1

L2 L1

208V

24V Transformer

High Pressure Sw.

Reversing Valve
Solenoid (24V)

Defrost Relay

Defrost
Therm.

5/370
Capacitor

Outdoor
Motor

Limit

Blower
Relay

HIGH (BLACK)

Black

(RED)

LOW

Indoor
Motor
7 1/2 MFD Capacitor

Defrost
Timer

Heater
Contactor

T2 T1

L2 L1

Fuse Panel

Thermal
Cutoff

Electric
Heater

FUSE A-60 A. Time Delay
FUSE B-30 A. Standard

Chart A

MODEL NO.	RUN CAP.
MHP30A	35/370
MHP36A	35/440

USE COPPER OR
ALUMINUM WIRE

	FACTORY WIRING	FIELD WIRING
Low Voltage	—————	- - - - -
High Voltage	—————	- - - - -

⚠ For 208V operation move this
wire to 208V transformer tap.

230/208-60-1

Equip.
Ground

4083-130 B

T874N1024/
Q674F1261

or

T874R1129/
Q674F1181




CHART A

MODEL NO.	RUN CAP.
MHP30A	35/370
MHP35A	35/440

⚠ For 208V operation move this wire to 208V transformer tap.

USE COPPER OR ALUMINUM WIRE

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----