
INSTALLATION INSTRUCTIONS

WALL MOUNTED PACKAGE AIR CONDITIONERS

MODELS WL602N



Bard Manufacturing Company
Bryan, Ohio 43506

*Since 1914...Moving ahead, just
as planned.*

Manual : 2100-351B
Supersedes: 2100-351A
File: Volume III Tab 16
Date: 06-28-99

Contents

| | | | |
|---|----------|--|-----------|
| Getting Other Information and Publications | 1 | Start Up | 13 |
| Wall Mount General Information | 2 | Important Installer Note | 13 |
| Heat Pump Wall Mount Model Nomenclature | 2 | Crankcase Heaters | 13 |
| Shipping Damage | 4 | High Pressure Switch | 13 |
| General | 4 | Three Phase Scroll Compressor Start Up | 13 |
| Duct Work | 4 | Service Hints | 13 |
| Condensate Drain | 5 | Sequence of Operation | 13 |
| Installation Instructions | 6 | Compressor Control Module | 13 |
| Wall Mounting Information | 6 | Adjustments | 14 |
| Mounting the Unit | 6 | Phase Monitor | 14 |
| Wiring – Main Power | 11 | Pressure Service Ports | 14 |
| Wiring – Low Voltage Wiring | 11 | Troubleshooting | 15 |
| | | Fan Blade Setting Dimensions | 15 |
| | | Removal of Fan Shroud | 15 |
| | | Refrigerant Charge | 15 |
| | | Pressure Table | 16 |
| | | Optional Accessories | 16 |
| Figures | | Tables | |
| Figure 1 Unit Dimensions | 3 | Table 1 Electrical Specifications | 4 |
| Figure 2 Mounting Instructions | 7 | Table 2 Thermostat Wire Size | 11 |
| Figure 3 Electric Heat Clearance | 8 | Table 3 Wall thermostat and Subbase | |
| Figure 4 Wall Mounting Instructions | 9 | Combinations | 11 |
| Figure 5 Wall Mounting Instructions | 9 | Table 4 Fan Blade Dimensions | 15 |
| Figure 6 Common Wall Mounting Installations | 10 | Table 5 Indoor Blower Performance | 15 |
| Figure 7 Unit 24V Terminal Board | 12 | Table 6 Refrigerant Charge | 15 |
| Figure 13 Fan Blade Setting | 15 | Table 7 Rated CFM and Rated ESP | 15 |
| | | Table 8 Maximum ESP of Operation | |
| | | Electric Heat Only | 15 |
| | | Table 9 Pressure Table | 16 |
| | | Table 10 Optional Accessories | 16 |

Getting Other Information and Publications

These publications can help you install the air conditioner or heat pump. You can usually find these at your local library or purchase them directly from the publisher. Be sure to consult current edition of each standard.

National Electrical CodeANSI/NFPA 70

Standard for the InstallationANSI/NFPA 90A
of Air Conditioning and
Ventilating Systems

Standard for Warm AirANSI/NFPA 90B
Heating and Air
Conditioning Systems

Load Calculation forACCA Manual J
Residential Winter and
Summer Air Conditioning

Duct Design for ResidentialACCA Manual D
Winter and Summer Air Conditioning
and Equipment Selection

For more information, contact these publishers:

ACCA — Air Conditioning Contractors of America
1712 New Hampshire Ave. N.W.
Washington, DC 20009
Telephone: (202) 483-9370
Fax: (202) 234-4721

ANSI — American National Standards Institute
11 West Street, 13th Floor
New York, NY 10036
Telephone: (212) 642-4900
Fax: (212) 302-1286


**ASHRAE — American Society of Heating
Refrigerating, and
Air Conditioning Engineers, Incorporated**
1791 Tullie Circle, N.E.
Atlanta, GA 30329-2305
Telephone: (404) 636-8400
Fax: (404) 321-5478

NFPA — National Fire Protection Association
Batterymarch Park
P.O. Box 9101
Quincy, MA 02269-9901
Telephone: (800) 344-3555
Fax: (617) 984-7057


Manufactured under the following U.S. patent numbers:
5,485,878; 5,301,777; 5,002,116; 4,924,934; 4,875,520;
4,825,936; 4,432,409

WALL MOUNT GENERAL INFORMATION

AIR CONDITIONING WALL MOUNT MODEL NOMENCLATURE



**FIGURE 1
UNIT DIMENSIONS**



**TABLE 1
ELECTRICAL SPECIFICATIONS**

| Model | SINGLE CIRCUIT | | | | | | DUAL CIRCUIT | | | | | | | | |
|------------------------------|---------------------------|-----------------------------------|-------------------------------------|--|-------------------------------------|-----------------------------|-------------------------------------|-------|---|-------|-------------------------------|-------|--------------------------|-------|-----|
| | Rated Volts & Phase | No. Field Power Circuits | ③ Minimum Circuit Ampacity | ① Maximum External Fuse or Ckt. Breaker | ② Field Power Wire Size | ② Ground Wire Size | ③ Minimum Circuit Ampacity | | ① Maximum External Fuse or Ckt. Breaker | | ② Field Power Wire Size | | ② Ground Wire Size | | |
| | | | | | | | CKT A | CKT B | CKT A | CKT B | CKT A | CKT B | CKT A | CKT B | |
| WL602NA00, A0Z A05 A10 | 230/208-1 | 1 | 44 | 60 | 8 | 10 | N/A | N/A | N/A | N/A | N/A | N/A | N/A | N/A | N/A |
| WL602NB00, B0Z B09 | 230/208-3 | 1 | 32 | 45 | 8 | 10 | N/A | N/A | N/A | N/A | N/A | N/A | N/A | N/A | N/A |

- ① Maximum size of the time delay fuse or HACR type circuit breaker for protection of field wiring conductors.
- ② Based on 75° C copper wire. All Wiring must conform to NEC and all local codes.
- ③ These "minimum Circuit Ampacity" values are to be used for sizing the field power conductors. Refer to the National Electric Code (latest revision), article 310 for power conductor sizing. *CAUTION: When more than one field power conductor circuit is run thru one conduit, the conductors must be derated. Pay special attention to note 8 of table 310 regarding Ampacity Adjustment Factors when more than 3 conductors are in a raceway.*

SHIPPING DAMAGE

Upon receipt of equipment, the carton should be checked for external signs of shipping damage. If damage is found, the receiving party must contact the last carrier immediately, preferably in writing, requesting inspection by the carrier's agent.

GENERAL

The equipment covered in this manual is to be installed by trained, experienced service and installation technicians.

The refrigerant system is completely assembled and charged. All internal wiring is complete.

The unit is designed for use with or without duct work. Flanges are provided for attaching the supply and return ducts.

These instructions explain the recommended method to install the air cooled self-contained unit and the electrical wiring connections to the unit.

These instructions and any instructions packaged with any separate equipment, required to make up the entire air conditioning system should be carefully read before beginning the installation. Note particularly any tags and/or labels attached to the equipment.

While these instructions are intended as a general recommended guide, they do not supersede any national and/or local codes in any way. Authorities having jurisdiction should be consulted before the installation is made. See Page 1 for information on codes and standards.

Size of unit for a proposed installation should be based on heat loss calculation made according to methods of Air Conditioning Contractors of America (ACCA). The air duct should be installed in accordance with the Standards of the National Fire Protection Association for the Installation of Air Conditioning and Ventilating Systems of Other Than Residence Type, NFPA No. 90A, and Residence Type Warm Air Heating and Air Conditioning Systems, NFPA No. 90B. Where local regulations are at a variance with instructions, installer should adhere to local codes.

DUCT WORK

All duct work, supply and return, must be properly sized for the design air flow requirement of the equipment. Air Conditioning Contractors of America (ACCA) is an excellent guide to proper sizing. All duct work or portions thereof not in the conditioned space should be properly insulated in order to both conserve energy and prevent condensation or moisture damage.

Design the duct work according to methods given by the Air Conditioning Contractors of America (ACCA). When duct runs through unheated spaces, it should be insulated with a minimum of one inch of insulation. Use insulation with a vapor barrier on the outside of the insulation. Flexible joints should be used to connect the duct work to the equipment in order to keep the noise transmission to a minimum.

A 1/4 inch clearance to combustible material for the first three feet of duct attached to the outlet air frame is required. See Wall Mounting Instructions and Figures 3 and 3A for further details.

Ducts through the walls must be insulated and all joints taped or sealed to prevent air or moisture entering the wall cavity.

Some installations may not require any return air duct. A metallic return air grille is required with installations not requiring a return air duct. The spacing between louvers on the grille shall not be larger than 5/8 inch.

Any grille that meets with 5/8 inch louver criteria may be used. It is recommended that Bard Return Air Grille Kit RG2 through RG5 or RFG2 through RFG5 be installed when no return duct is used. Contact distributor or factory for ordering information. If using a return air filter grille, filters must be of sufficient size to allow a maximum velocity of 400 fpm.

NOTE: If no return air duct is used, applicable installation codes may limit this cabinet to installation only in a single story structure.

CONDENSATE DRAIN

A plastic drain hose extends from the drain pan at the top of the unit down to the unit base. There are openings in the unit base for the drain hose to pass through. In the event the drain hose is connected to a drain system of some type, it must be an open or vented type system to assure proper drainage.

INSTALLATION INSTRUCTIONS

WALL MOUNTING INFORMATION

1. Two holes for the supply and return air openings must be cut through the wall as shown in Figure 3.
2. On wood frame walls, the wall construction must be strong and rigid enough to carry the weight of the unit without transmitting any unit vibration.



WARNING

Fire hazard can result if 1/4 inch clearance to combustible materials for supply air duct is not maintained. See Figure 2.

3. Concrete block walls must be thoroughly inspected to insure that they are capable of carrying the weight of the installed unit.

MOUNTING THE UNIT

1. These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides. A bottom mounting bracket is provided for ease of installation, but is not required.
2. The unit itself is suitable for 0 inch clearance, but the supply air duct flange and the first 3 feet of supply air duct require a minimum of 1/4 inch clearance to combustible material. If a combustible wall use a minimum of 30-1/2" x 10-1/2" dimensions for sizing. However it is generally recommended that a 1 inch clearance is used for ease of installation and maintaining the required clearance to combustible material. The supply air opening would then be 32" x 12". See Figures 2 and 3 for details.



WARNING

Failure to provide the 1/4 inch clearance between the supply duct and a combustible surface for the first 3 feet of duct can result in fire causing damage, injury or death.

3. Locate and mark lag bolt locations and bottom mounting bracket location. See Figure 2.
4. Mount bottom mounting bracket.
5. Hook top rain flashing under back bend of top. Top rain flashing is shipped secured to the right side of the back.
6. Position unit in opening and secure with 5/16 lag bolts; use 7/8 inch diameter flat washers on the lag bolts.
7. Secure rain flashing to wall and caulk across entire length of top. See Figure 2.
8. For additional mounting rigidity, the return air and supply air frames or collars can be drilled and screwed or welded to the structural wall itself (depending upon wall construction). Be sure to observe required clearance if combustible wall.
9. On side by side installations, maintain a minimum of 20 inches clearance on right side to allow access to control panel and heat strips, and to allow proper airflow to the outdoor coil. Additional clearance may be required to meet local or national codes.

FIGURE 2
MOUNTING INSTRUCTIONS





FIGURE 3
ELECTRIC HEAT CLEARANCE



MIS-277


WARNING

A *minimum* of 1/4 inch clearance must be maintained between the supply air duct and combustible materials. This is required for the first 3 feet of ducting.

It is important to insure that the 1/4 inch minimum spacing is maintained at all points.


Failure to do this could result in overheating the combustible material and may result in a fire causing damage, injury or death.

FIGURE 4
WALL MOUNTING INSTRUCTIONS




MIS-948

FIGURE 5
WALL MOUNTING INSTRUCTIONS




MIS-949


**FIGURE 6
COMMON WALL MOUNTING INSTALLATIONS**




FREE AIR FLOW NO DUCT



DUCTED SUPPLY RETURN AT UNIT



FALSE WALL INSTALLATION



CLOSET INSTALLATION

MIS-1050

WIRING – MAIN POWER

Refer to the unit rating plate for wire sizing information and maximum fuse or “HACR” type circuit breaker size. Each outdoor unit is marked with a “Minimum Circuit Ampacity”. This means that the field wiring used must be sized to carry that amount of current. Depending on the installed KW of electric heat, there may be two field power circuits required. If this is the case, the unit serial plate will so indicate. All models are suitable only for connection with copper wire. Each unit and/or wiring diagram will be marked “Use Copper Conductors Only”. These instructions **must be** adhered to. Refer to the National Electrical Code (NEC) for complete current carrying capacity data on the various insulation grades of wiring material. All wiring must conform to NEC and all local codes.

The electrical data lists fuse and wire sizes (75° C copper) for all models including the most commonly used heater sizes. Also shown are the number of field power circuits required for the various models with heaters.

The unit rating plate lists a “Maximum Time Delay Relay Fuse” or “HACR” type circuit breaker that is to be used with the equipment. The correct size must be used for proper circuit protection and also to assure that there will be no nuisance tripping due to the momentary high starting current of the compressor motor.

The disconnect access door on this unit may be locked to prevent unauthorized access to the disconnect. To convert for the locking capability, bend the tab locate in the bottom left hand corner of the disconnect opening under the disconnect access panel straight out. This tab will now line up with the slot in the door. When shut a padlock may be placed through the hole in the tab preventing entry.

See “Start Up” section for important information on three phase scroll compressor start ups.

WIRING – LOW VOLTAGE WIRING

230 / 208V, 1 phase and 3 phase equipment dual primary voltage transformers. All equipment leaves the factory wired on 240V tap. For 208V operation, reconnect from 240V to 208V tap. The acceptable operating voltage range for the 240 and 208V taps are:

| TAP | RANGE |
|-----|-----------|
| 240 | 253 – 216 |
| 208 | 220 – 187 |

NOTE: The voltage should be measured at the field power connection point in the unit and while the unit is operating at full load (maximum amperage operating condition).

Five (5) wires should be run from thermostat subbase to the 24V terminal board in the unit. A five conductor, 18 gauge copper, color-coded thermostat cable is recommended. The connection points are shown in Figure 7:


**TABLE 2
THERMOSTAT WIRE SIZE**

| Transformer VA | FLA | Wire Gauge | Maximum Distance In Feet |
|----------------|-----|------------|--------------------------|
| 55 | 2.3 | 20 gauge | 45 |
| | | 18 gauge | 60 |
| | | 16 gauge | 100 |
| | | 14 gauge | 160 |
| | | 12 gauge | 250 |


**TABLE 3
WALL THERMOSTAT AND SUBBASE COMBINATIONS**

| Thermostat | Subbase | Predominate Features |
|-----------------------|-----------------------|---|
| 8403-002 T87F3111 | 8404-003 Q539A1220 | 1 stage heat, 1 stage cool System: heat-off-cool Fan: auto-on |
| 8403-041 T8034C | --- | 1 stage heat, 1 stage cool System: heat-off-cool Fan: auto-on |
| 8403-019 T874C1760 | 8404-012 Q674A1001 | 1 stage cool, 2 stage heat System: heat-auto-cool Fan: auto-on |
| 8403-021 T874D1934 | 8404-012 Q674A1001 | 2 stage cool, 2 stage heat System: heat-auto-cool Fan: auto-on |
| 8403-035 1F95-80 | --- | 2 stage cool, 2 stage heat Electronic 7 day programming |
| 8403-043 CM-200 | --- | 1 stage heat, 1 stage cool System: heat-off-cool Fan: auto-on |

**FIGURE 7
UNIT 24V TERMINAL BOARD**



OPTIONAL ECONOMIZER LOW VOLTAGE WIRING



MIS-1373

IMPORTANT INSTALLER NOTE

For improved start up performance wash the indoor coil with a dish washing detergent.

CRANKCASE HEATERS

WA602N units are not provided with crankcase heat. These units utilize scroll compressors which do not require crankcase heat in this application.

HIGH PRESSURE SWITCH

The models are supplied with a remote reset high pressure switch. If tripped, this pressure switch may be reset by turning the thermostat off then back on again.

THREE PHASE SCROLL COMPRESSOR START UP INFORMATION

Scroll compressors, like several other types of compressors, will only compress in one rotational direction. Direction of rotation is not an issue with single phase compressors since they will always start and run in the proper direction.

However, three phase compressors will rotate in either direction depending upon phasing of the power. Since there is a 50-50 chance of connecting power in such a way as to cause rotation in the reverse direction, verification of proper rotation must be made. Verification of proper rotation direction is made by observing that suction pressure drops and discharge pressure rises when the compressor is energized. Reverse rotation also results in an elevated sound level over that with correct rotation, as well as, substantially reduced current draw compared to tabulated values.

Verification of *proper rotation* must be made at the time the equipment is put into service. If improper rotation is corrected at this time there will be no negative impact on the durability of the compressor. However, reverse operation for over one hour may have a negative impact on the bearing due to oil pump out.

NOTE: If compressor is allowed to run in reverse rotation for several minutes, the compressor's internal protector will trip.

All three phase ZR3 compressors are wired identically internally. As a result, once the correct phasing is determined for a specific system or installation, connecting properly phased power leads to the same Fusite terminal should maintain proper rotation direction.

The direction of rotation of the compressor may be changed by reversing any two line connections to the unit.

SERVICE HINTS

1. Caution homeowner to maintain clean air filters at all times. Also, not to needlessly close off supply and return air registers. This reduces air flow through the system, which shortens equipment service life as well as increasing operating costs.
2. Switching to heating cycle at 75° F or higher outside temperature may cause a nuisance trip of the remote reset high pressure switch. Turn thermostat off then on to reset the high pressure switch.
3. Check all power fuses or circuit breakers to be sure they are the correct rating.
4. Periodic cleaning of the outdoor coil to permit full and unrestricted airflow circulation is essential.

SEQUENCE OF OPERATION

COOLING – Circuit R-Y makes at thermostat pulling in compressor contactor, starting the compressor and outdoor motor. The G (indoor motor) circuit is automatically completed on any call for cooling operation or can be energized by manual fan switch on subbase of constant air circulation.

COMPRESSOR CONTROL MODULE

The compressor control module is standard on the models covered by this manual. The compressor control is an anti-short cycle/lockout timer with high and low pressure switch monitoring and alarm relay output.

Adjustable Delay On Make And Break Timer

On initial power up or any time power is interrupted to the unit the *delay on make* period begins which will be 2 minutes plus 10% of the *delay on break* setting. When the delay on make is complete and the high pressure switch (and low pressure switch if employed) is closed, the compressor contactor is energized. Upon shutdown the delay or break timer starts and prevents restart until the delay on break and delay on make periods have expired.

During routine operation of the unit with no power interruptions the compressor will operate on demand with no delay.

High Pressure Switch and Lockout Sequence

If the high pressure switch opens, the compressor contactor will de-energize immediately. The lockout timer will go into a *soft lockout* and stay in soft lockout until the high pressure switch closes and the delay on break time has expired. If the high pressure switch opens again in this same operating cycle the unit will go into *manual lockout* condition and the alarm relay circuit will energize. Recycling the wall thermostat resets the manual lockout.

Low Pressure Switch, Bypass, and Lockout Sequence

If the low pressure switch opens for more than 120 seconds, the compressor contactor will de-energize and go into a soft lockout. Regardless of the state of the low pressure switch, the contactor will reenergize after the delay on make time delay has expired. If the low pressure switch remains open, or opens again for longer than 120 seconds the unit will go into manual lockout condition and the alarm relay circuit will energize. Recycling the wall thermostat resets the manual lockout.

Alarm Relay Output

Alarm terminal is output connection for applications where alarm relay is employed. This terminal is powered whenever compressor is locked out due to HPC or LPC sequences as described.

NOTE: Both high and low pressure switch controls are inherently automatic reset devices. The high pressure switch and low pressure switch cut out and cut in settings are fixed by specific air conditioner or heat pump unit model. The lockout features, both soft and manual, are a function of the Compressor Control Module.

ADJUSTMENTS

Adjustable Delay on Make and Delay on Break Timer

The potentiometer is used to select Delay on Break time from 30 seconds to 5 minutes. Delay on Make (DOM) timing on power-up and after power interruptions is equal to 2 minutes plus 10% of Delay on Break (DOB) setting:

| | | |
|--------------------------|------------------|-----|
| 0.5 minute (30 seconds) | DOB = 123 second | DOM |
| 1.0 minute (60 seconds) | DOB = 126 second | DOM |
| 2.0 minute (120 seconds) | DOB = 132 second | DOM |
| 3.0 minute (180 seconds) | DOB = 138 second | DOM |
| 4.0 minute (240 seconds) | DOB = 144 second | DOM |
| 5.0 minute (300 seconds) | DOB = 150 second | DOM |

During routine operation of the unit with no power interruptions the compressor will operate on demand with no delay.

Typical Settings for Dual Unit Installation:

Unit No. 1: DOB set at 2 minutes, and DOM is 132 seconds

Unit No. 2: DOB set at 4 minutes, and DOM is 144 seconds

PHASE MONITOR

All units with three phase scroll compressors are equipped with a 3 phase line monitor to prevent compressor damage due to phase reversal.

The phase monitor in this unit is equipped with two LEDs. If the Y signal is present at the phase monitor and phases are correct the green LED will light.

If phases are reversed, the red fault LED will be lit and compressor operation is inhibited.

If a fault condition occurs, reverse two of the supply leads to the unit. Do not reverse any of the unit factory wires as damage may occur.

PRESSURE SERVICE PORTS

High and low pressure service ports are installed on all units so that the system operating pressures can be observed. A pressure table can be found later in the manual covering all models. It is imperative to match the correct pressure table to the unit by model number.

TROUBLESHOOTING

FAN BLADE SETTING DIMENSIONS

Shown in Figure 8 is the correct fan blade setting dimension for proper air delivery across the outdoor coil.

Any service work requiring removal or adjustment in the fan and/or motor area will require that the dimensions below be checked and blade adjusted in or out on the motor shaft accordingly.

FIGURE 8




TABLE 4

| Model | Dimension A |
|--------|-------------|
| WL602N | 1.75 |

REMOVAL OF FAN SHROUD

1. Disconnect all power to the unit.
2. Remove the screws holding both grilles, one on each side of unit, and remove grilles.

TABLE 5
INDOOR BLOWER PERFORMANCE
CFM @ 230V

| E.S.P. In H ₂ O | WA601N | |
|-------------------------------|-------------|-------------|
| | High 230V | |
| | Dry Coil | Wet Coil |
| .0 | 1775 | 1575 |
| .1 | 1675 | 1500 |
| .2 | 1575 | 1425 |

3. Remove screws holding fan shroud to condenser and bottom. Nine (9) screws.
4. Unwire condenser fan motor.
5. Slide complete motor, fan blade, and shroud assembly out the left side of the unit.
6. Service motor/fan as needed.
7. Reverse steps to reinstall.

REFRIGERANT CHARGE

The correct system R-22 charge is shown on the unit rating plate. Optimum unit performance will occur with a refrigerant charge resulting in a suction line temperature (6" from compressor) as shown in Table 5.

TABLE 6
REFRIGERANT CHARGE

| Model | Rated Airflow | 95 OD Temperature | 82 OD Temperature |
|--------|------------------|----------------------|----------------------|
| WL602N | 1700 | 53 - 55 | 60 - 62 |

The suction line temperatures in table above are based upon 80° F dry bulb / 67° F wet bulb (50% R.H.) temperature and rated airflow across the evaporator during cooling cycle.

TABLE 7
RATED CFM AND ESP

| Model | Rated CFM * | Rated ESP * | Recommended Airflow Range |
|--------|----------------|----------------|------------------------------|
| WL602N | 1425 | .20 | 1775 - 1425 |

* Rated CFM and ESP on high speed tap.

TABLE 8
MAXIMUM ESP OF OPERATION
ELECTRIC HEAT ONLY

| Model | ESP | |
|--------|-----|----|
| WL602N | A05 | .4 |
| | A10 | .3 |
| | B09 | .3 |

Values shown are for units equipped with standard 1" throw-away filters or 1" washable filter. Derate ESP by .15 for 2" pleated filters.

**TABLE 9
PRESSURE TABLE**

COOLING

Air Temperature Entering Outdoor Coil °F

| Model | Return Air Temperature | Pressure | 75 | 80 | 85 | 90 | 95 | 100 | 105 | 110 | 115 |
|--------|------------------------|-----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| WL602N | 75 deg. DB | Low Side | 71 | 72 | 74 | 75 | 76 | 77 | 78 | 78 | 79 |
| | 62 deg. WB | High Side | 233 | 247 | 262 | 278 | 295 | 313 | 331 | 351 | 371 |
| | 80 deg. DB | Low Side | 76 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 |
| | 67 deg. WB | High Side | 237 | 253 | 269 | 285 | 303 | 321 | 340 | 360 | 381 |
| | 85 deg. DB | Low Side | 84 | 85 | 85 | 86 | 87 | 88 | 89 | 90 | 91 |
| | 72 deg. WB | High Side | 245 | 261 | 278 | 296 | 314 | 333 | 353 | 373 | 394 |



Low side pressure ± 2 PSIG

High side pressure ± 5 PSIG

Tables are based upon rated CFM (airflow) across the evaporator coil. If there is any doubt as to correct operating charge being in the system, the charge should be removed, system evacuated and recharged to serial plate instructions.

**TABLE 10
OPTIONAL ACCESSORIES**

| Part Number | Description | WL602NA | WL602NB |
|-------------|-----------------|---------|---------|
| BOP-5 | Blank Off Plate | X | X |
| CMC-15 | Start Kit | X | X |





| COMPONENT CODE | INDOOR BLOWER RELAY | INDOOR BLOWER MOTOR | COMPRESSOR | HEATER CONTACTOR #1 | HEATER CONTACTOR #2 | INDOOR BLOWER CAPACITOR | INDOOR BLOWER MOTOR |
|----------------|-------------------------|---------------------|----------------------------|---------------------|----------------------|-------------------------|----------------------|
| CB1 | CIRCUIT BREAKER #1 | LAC | LOW AMBIENT CONTROL | LOR | LOCK OUT RELAY | LPC | LOW PRESSURE CONTROL |
| CB2 | CIRCUIT BREAKER #2 | LPA | LOW PRESSURE BYPASS | LPS | LOW PRESSURE CONTROL | LPH | LIMIT SWITCH |
| CC | COMPRESSOR CONTACTOR | PLC | OUTDOOR FAN MOTOR | PLI | PLUS #1 | SK | START KIT |
| CC | DUAL CAN CAPACITOR | PFI | TRANSFORMER | T | TERMINAL BLOCK | TR | TRIP |
| CAU | EQUIPMENT GROUND | TR | TERMINAL BLOCK | TR | TRIP | TR | TRIP |
| H1 | HEAT STRIP #1 | TR | LOW VOLTAGE TERMINAL BLOCK | TR | TRIP | TR | TRIP |
| H2 | HEAT STRIP #2 | TR | LOW VOLTAGE TERMINAL BLOCK | TR | TRIP | TR | TRIP |
| H1 | HEATER CONTACTOR #1 | TR | THERMAL CUTOFF | TR | TRIP | TR | TRIP |
| H2 | HEATER CONTACTOR #2 | TR | TIME DELAY RELAY | TR | TRIP | TR | TRIP |
| IBC | INDOOR BLOWER CAPACITOR | TR | | TR | TRIP | TR | TRIP |
| IM | INDOOR BLOWER MOTOR | TR | | TR | TRIP | TR | TRIP |

| Labeled Wires Connect If No Options Used. | | | None Red Wire To 208V Tap For 208V Operation | | | RED (LOW) BLACK (HIGH) |
|---|-------|----------|--|-------|-----|------------------------|
| Factory Std. | Field | Optional | Black | Brown | Red | Orange |
| High Voltage | --- | --- | Y | G | B | W |
| Low Voltage | --- | --- | Y | PK | L | |
| Accessory | --- | --- | Y | PK | L | |

| Color Code | | | |
|------------|--------|-----|----------|
| V | YELLOW | PR | PURPLE |
| Y | GREEN | PK | PINK |
| G | BLUE | L | LAVENDER |
| B | WHITE | (S) | SLATE |
| BL | WHITE | (S) | SLATE |
| W | WHITE | (S) | SLATE |

| BARD MFG. CO. | |
|---------------|------------|
| DRG. NO. | 4035-112 A |
| DRN. CDR. | |
| CHK./APPR. | |



| COMPONENT CODE | |
|----------------|----------------------------|
| ALR | ALARM RELAY |
| CB1 | CIRCUIT BREAKER #1 |
| CB2 | CIRCUIT BREAKER #2 |
| CC | COMPRESSOR CONTACTOR |
| CCX | COMPRESSOR CONTROL MODULE |
| CCP | COMPRESSOR |
| CCD | EQUIPMENT GROUND |
| H1 | HEAT STRIP #1 |
| H2 | HEAT STRIP #2 |
| HCL | HEATER CONTACTOR #1 |
| H2C | HEATER CONTACTOR #2 |
| HPC | HIGH PRESSURE CONTROL |
| IBC | INDOOR BLOWER CAPACITOR |
| IBM | INDOOR BLOWER MOTOR |
| IBR | INDOOR BLOWER RELAY |
| LAC | LOW AMBIENT CONTROL |
| LPC | LOW PRESSURE CONTROL |
| LS | LIMIT SWITCH |
| OPC | OUTDOOR FAN CAPACITOR |
| OFH | OUTDOOR FAN MOTOR |
| PL1 | PLUG #1 |
| PH | PHASE MONITOR |
| TR | TRANSFORMER |
| IB, IB2 | TERMINAL BLOCK |
| IBL | LOW VOLTAGE TERMINAL BLOCK |
| TCO | THERMAL CUTOFF |

▲ Labeled wires connect if no options used. ▲ HOME RED WIRE TO 208V TAP FOR 208V OPERATION ▲ RED (LOW) BLACK (HIGH) WIRE APPLICABLE HERE

| HIGH VOLTAGE | FACTORY STD. | FIELD | OPTIONAL |
|--------------|--------------|-------|----------|
| LOW VOLTAGE | | | |
| ACCESSORY | | | |

| COLOR CODE | |
|------------|----------|
| BK | BLACK |
| BR | BROWN |
| R | RED |
| O | ORANGE |
| Y | YELLOW |
| V | VIOLET |
| P | PURPLE |
| GY | GRAY |
| SL | SLATE |
| PK | PINK |
| L | LAVENDER |

BARD MFG. CO.
 4095-227 C