
REPLACEMENT PARTS MANUAL WALL MOUNT HEATER PACKAGE

Models:

**EHWA05-A05L, EHWA05-A10L, EHWA05-A15L,
EHWA05-B06L, EWHA05-B09L, EHWA05-B15L,
EHWA05-C09L, EHWA05-C15L, EHWA05HA10L,
EHWA05HA15L, EHWA05HB09L, EHWA05HB15L,
EHWA05NA05L, EHWA05NA10L, EHWA60-A05L,
EHWA60-B09L**

General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

Contents

Description	Page
Heater Packages / Air Conditioner	
♦ Exploded View	1
♦ Usage List	2

Important



- Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plates.



BARD MANUFACTURING COMPANY
Bryan, Ohio 43506
Since 1914 . . . Moving ahead, just as planned

Manual: 2110-613A
Supersedes: 2110-613
File: Tab 18
Date: 01-15-02

AIR CONDITIONING HEATER PACKAGES



SEXP-165

AIR CONDITIONING HEATER PACKAGES

Drawing No.	Part No.	Description	EHWA05-A05L	EHWA05-A10L	EHWA05-A15L	EHWA05-B06L	EHWA05-B09L	EHWA05A-C09L	EHWA05A-C15L	EHWA05HA10L	EHWA05HA15L	EHWA05HB09L	EHWA05HB15L	EHWA05NA05L	EHWA05NA10L	EHWA60-A05L	EHWA60-B09L
1	8604-089	Heat Strip 5 KW	X		X					X	X			X		X	
1	8604-091	Heat Strip 10 KW		X	X					X	X				X		
1	8604-049	Heat Strip 6 KW				X							X				
1	8604-048	Heat Strip 9 KW					X					X	X				X
1	8604-100	Heat Strip 6 KW							X								
1	8604-101	Heat Strip 9 KW						X	X								
2	127Y210	Heater Control Base	X	X	X	X	X			X	X	X	X	X	X	X	X
2	127-321	Heater Control Base						X	X								
3	8402-074	Limit Control	X			X	X	X				X			X	X	X
3	8402-075	Limit Control			X				X		X		X				
3	8402-065	Limit Control		X						X				X			
4	8402-093	Thermal Cutoff	1		3						3				2	1	
4	8402-092	Thermal Cutoff				2	2					2	4	1			2
4	8402-094	Thermal Cutoff						2	4								
4	8402-096	Thermal Cutoff		2						2							
5	8615-067	Disconnect Switch						X	X								
5	8615-037	Circuit Breaker 30A			X						X						
5	8615-042	Circuit Breaker 35A 3 Ph				X	X										
5	8615-040	Circuit Breaker 50A	X											X			
5	8615-041	Circuit Breaker 60A 3 Ph		X	X					2	2				X	X	
5	8615-044	Circuit Breaker 45A 3 Ph															X
5	8615-046	Circuit Breaker 60A										X	X				
5	8615-051	Circuit Breaker 25A 3 Ph										X	X				
6	8401-006	Heat Contactor	X	X	2	X	X			X	X	X	2	X	X	X	X
6	8401-002	Heat Contactor						X	2	X	X						
7	8615-047	Jumper Bar Base			X					X							
7	8615-048	Jumper Bar Base									X						
8	8611-006	Ground Terminal			X					X	X		X				
9	8615-049	Jumper Bar Cover			X					X							
9	8615-050	Jumper Bar Cover									X						
NS	4097-120	Wiring Diagram	X											X		X	
NS	4097-140	Wiring Diagram		X											X		
NS	4097-152	Wiring Diagram			X												
NS	4097-220	Wiring Diagram				X	X										X
NS	4097-233	Wiring Diagram											X				
NS	4097-322	Wiring Diagram						X									
NS	4097-332	Wiring Diagram							X								
NS	4097-163	Wiring Diagram									X						
NS	4097-142	Wiring Diagram								X							
NS	4097-221	Wiring Diagram										X					

NS = Not Shown