



- 1 Add jumper Rc to Rh. Set heat anticipators at .40A.
- 2 Remove jumper for 2-stage heat.
- 3 Set heat anticipators for W1 and W2 at .40A.