



T874C1000 Thermostat
Q674A1001 Subbase

or

T872C1004 Thermostat
Q672A1005 Subbase 2

NEC Class 2
24V Wiring

24V Terminal
Block

1 Add jumper Rc to Rh.

2 Set heat anticipators for W1
@ .80A and W2 @ .40A.

Single Package
Air Conditioner
4 and 5 Ton
w/13.5 Kw

Fused
Disconnect
Switch

USE COPPER OR
ALUMINUM WIRE

415/380-50-3

Factory Wiring
Field Wiring

4002-630D