



Emergency Signal Light

TB72C1004 Thermostat
Q672F1026 Subbase

NEC Class 2
24V Wiring

Defrost Thermostat

USE COPPER OR ALUMINUM WIRE

- 1 3-terminal capacitor provides off-cycle crankcase heat.
- 2 Set heat anticipators at .40A for W1 and W2.
- 3 Reroute jumper from X2-W2 to X2-E.

Single Package Heat Pump
2 and 2-1/2 Ton
One Motor
w/8 or 10kw

Factory Wiring ———
Field Wiring - - - - -

4003-130 B