



- 1 Capacitor provides off-cycle crankcase heat.
- 2 Set heat anticipators at .40A
- 3 Reroute jumper from X2-W2 to X2-E.