



Emergency Signal Light
 T972C1004 Thermostat
 Q672F1026 Subbase ①

NEC Class 2
 24V Wiring

- ① Set heat anticipators at .40A
- ② Reroute jumper from X2-W2 to X2-E.

USE COPPER OR
 ALUMINUM WIRE

Single Package
 Heat Pump
 3-Ton

Factory Wiring ———
 Field Wiring - - - - -

Fused Disconnect Switch
 415/380-50-3