



- ① Reroute jumper from X2-W2 to X2-E.
- ② Set heat anticipators at .40A for W1

Fused Disconnect Switch

USE COPPER OR ALUMINUM WIRE

230/208-60-1

Factory Wiring _____
 Field Wiring - - - - -

Single Package Heat Pump
 4 and 5 Ton