



Factory Wiring ———
Field Wiring - - - - -

USE COPPER OR ALUMINUM WIRE

- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.

Models
20WA1 & 24WA2
w/4 or 5KW