



USE COPPER OR ALUMINUM WIRE

- ⚠️ 1 Capacitor provides off-cycle crankcase heat.
- ⚠️ 2 See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠️ 3 For 208V operation move this wire to 208V transformer tap.

MODELS
20WA1 & 24WA2
W/ 8 OR 10KW

| FACTORY WIRING | FIELD WIRING |
|------------------|--------------|
| Low Voltage ——— | ----- |
| High Voltage ——— | ----- |

240/220-50-1