



USE COPPER OR ALUMINUM WIRE

- ⚠ 1 Capacitor provides off-cycle crankcase heat.
- ⚠ 2 See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ 3 For 208V operation move this wire to 208V transformer tap.

**Models
20WA1 & 24WA2
w/8 or 10Kw**

Factory Wiring ———
Field Wiring - - - - -