


USE COPPER OR ALUMINUM WIRE

- ① Capacitor provides off-cycle crankcase heat.
- ② See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation, move this wire to 208V transformer tap.



230/208-60-1

Models
20WA1 & 24WA2
4 or 5Kw

Factory Wiring ———
Field Wiring - - - - -