



5-Minute
Anti-Cycle
Relay

USE COPPER OR
ALUMINUM WIRE

- ⚠️ 1 Capacitor provides off-cycle crankcase heat.
- ⚠️ 2 See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠️ 3 For 208V operation move this wire to 208V transformer tap.

230/208-60-1

MODELS
20WA1 & 24WA2
w/4 or 5Kw

Factory Wiring ———
Field Wiring - - - - -