



USE COPPER OR ALUMINUM WIRE

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

230/208-60-1

MODELS  
24WA4

Factory Wiring \_\_\_\_\_  
Field Wiring -----

4007-855A