



USE COPPER OR ALUMINUM WIRE

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

230/208-60-1

MODEL
24VAS
W/ 4
OR 5KW

FACTORY WIRING	FIELD WIRING
Low Voltage ———	-----
High Voltage ———	-----

4007865A