



- ⚠ 1 3-Terminal capacitor provides off-cycle crankcase heat.
- ⚠ 2 Set heat anticipators at .40A for W1 and W2.
- ⚠ 3 Reroute jumper from X2-W2 to X2-E.

Factory wiring ———
Field Wiring - - - - -

USE COPPER OR ALUMINUM WIRE

Model
48WH1
w/10 Kw