



Fuse A - 60A Time Delay
 Fuse B - 60A Standard

Field Wiring - - - - -
 Factory Wiring _____

- 2 Set heat anticipators at .40A for W1 and .80 for W2.
- 3 Reroute jumper from X2-W2 to X2-E.
- 4 Remove this jumper if outdoor stat is used. Wire stat between terminals W2 and F.

USE COPPER OR ALUMINUM WIRE

Model
 48WH1
 w/20Kw