



⚠ If there is an X1 and X2 terminal on Q674L1181, jumper them together and connect from C to either one.

USE COPPER OR ALUMINUM WIRE	FACTORY WIRING	FIELD WIRING
	Low Voltage _____	-----
	High Voltage _____	-----

⚠ For 208V operation move this wire to 208V transformer tap **4014-211E**