



USE COPPER OR ALUMINUM WIRE

CKT.

230/208-60-3

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----

⚠ If there is an X1 and X2 terminal on Q674L118 jumper them together and connect from C to either one.

⚠ For 208V operation move this wire to 208V transformer tap.

4014-221F