



USE COPPER OR ALUMINUM WIRE

CKT.
230/208-60-3

⚠ If there is an X1 and X2 terminal on Q674L1181 jumper them together and connect from C to either one.
⚠ For 208V operation move this wire to 208V transformer tap.

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----