



- ① Reroute jumper from X2-W2 to X2-E.
- ② Set heat anticipators at .40A.

Factory Wiring ———
Field Wiring - - - -

Fused Disconnect Switch

USE COPPER OR ALUMINUM WIRE

460V 60 Hz 3-Ph

Model 48W111