



- ⚠ FOR ANTIFREEZE LOOP APPLICATIONS, CHANGE LOW PRESSURE SWITCH TO YELLOW LEADS ON YELLOW WIRES COMING OFF OF COMPRESSOR CONTROL MODULE "LPC" TERMINALS
- ⚠ REMOVE JUMPER WHEN CS2000 ENERGY MONITOR IS INSTALLED
- ⚠ REMOVE WIRE FROM TERMINAL Y2 AND TAPE OFF WHEN LOWER FULL LOAD CFM DESIRED

**STEPDOWN TRANSFORMER CLASS CC FUSE**

MODEL	W / ERV	NO ERV
QW2S	5	3.2
QW3S	5	3.2
QW4S	7	3.2
QW5S	7	5

**⚠ DANGER**  
ELECTRICAL SHOCK HAZARD  
DISCONNECT POWER BEFORE SERVICING

99 Wire Identification numbers for Bard use only.

**⚠ WARNING**  
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75°C

	Factory	Field	Optional
High Voltage	---	---	---
Low Voltage	---	---	---

Bard Mfg. Co. Bryan, Ohio  
4113C301 A

**COMPOSITE WIRING DIAGRAM**  
460/60-3