



⚠ 1 FOR **ENERGY RECOVERY VENTILATOR** WITH CO2 CONTROL, **DO NOT** CONNECT "A" OCCUPANCY INPUT BETWEEN THERMOSTAT AND LOW VOLTAGE TERMINAL STRIP. **DO MAKE** THIS CONNECTION WHEN APPLYING A **COMMERCIAL ROOM VENTILATOR** WITH CO2 CONTROL.