



For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

230/208-60-1 Per Nameplate
Hi Voltage Field Connections

R Vent option only

Ground Lug (11)

Ground Eyelet

1
2
3

Compressor Contactor (7)

Compressor Capacitor

Herm

Compressor

Outdoor Fan Motor

Low Ambient Control (opt.)

Hi Press. Control

Low Press. Control

Reversing Valve

Outdoor Temp Switch (Opt.)

Condenser Section

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
ELECTRICAL SHOCK HAZARD
DISCONNECT POWER BEFORE SERVICING.

A → **A**
Same Letter Designated Wires Connect if Option Not Used
"A" & "C" No Control Option
"B" Only Freeze Stat & No ODT

	Factory	Field	Optional	Wire Identification numbers for Bard use only.
High Voltage				
Low Voltage				
				4100-126 D

NOTE: JUMPER PLUG MUST BE INSTALLED WHEN NO VENT OPTION IS INSTALLED

Wire trucked in cable duct when no OD (only use with LAC)

