



For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

460-60-3 Per Nameplate
Hi Voltage Field Connections L1 L2 L3

R Vent option only

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
ELECTRICAL SHOCK HAZARD
DISCONNECT POWER BEFORE SERVICING.

	Factory	Field	Optional
High Voltage			
Low Voltage			

Wire Identification numbers for Bard use only.
4100-326 F

A → **A**
Same Letter Designated Wires Connect if Option Not Used
"A" & "C" No Control Option
"B" Only Freeze Stat & No ODT

NOTE: JUMPER PLUG MUST BE INSTALLED WHEN NO VENT OPTION IS INSTALLED

Evaporator Section

Condenser Section

Upper Low Voltage Tb

Upper Low Voltage Plug

Low Voltage Terminal Strip

