



For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

R Vent option only

230/208-60-1
Per Nameplate
Hi Voltage
Field Connections

WARNING
USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT LEAST
75° C.

DANGER
*ELECTRICAL SHOCK HAZARD
*DISCONNECT POWER BEFORE
SERVICING.

A → A
Same Letter Designated
Wires Connect if Option Not Used

NOTE: JUMPER PLUG MUST BE INSTALLED
WHEN NO VENT OPTION IS INSTALLED (28)

	Factory	Field	Optional
High Voltage			
Low Voltage			

Wire Identification numbers for Bard use only.
4107-106 A