



**Outdoor Section**

**Control Panel Section**

**Indoor Section**

Outdoor Fan Motor

Motor Capacitor

Transformer

"A" Wires connect if option not used.

Multiplier

Step Down Transformer  
7A class CC Fuse

Compressor

Fuse Block

High Pressure Switch

Low Pressure Switch

Low Ambient Control (optional)

Compressor Control Module

Compressor Contactor

Step Down Transformer

Factory Field Optional

High Voltage  
Low Voltage

**460 Volt Package Unit Diagram**

**WARNING**  
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

**DANGER**  
ELECTRICAL SHOCK HAZARD  
DISCONNECT POWER BEFORE SERVICING.

Wire Identification numbers for Bard use only.

**Bard**  
SINCE 1914  
Bard Mfg. Co.  
Bryan, Ohio

4109-302 B

460-60-3

4 pin plug for Indoor Blower Motor

6 pin plug for Heater Package

5 pin plug for Indoor Blower Motor