



**Outdoor Section**

**Control Panel Section**

**Indoor Section**

Outdoor Fan Motor

Motor Capacitor

Multiplier

Transformer

"A" Wires connect if option not used.

Terminal Block (Optional)

Fan Relay

Step Down Transformer  
7A class CC Fuse

Compressor

Fuse Block

High Pressure Switch

Low Pressure Switch

Low Ambient Control (optional)

Compressor Control Module

Compressor Contactor

Step Down Transformer

	Factory	Field	Optional
High Voltage	-----	-----	-----
Low Voltage	-----	-----	-----

**460 Volt Package Unit Diagram**

**WARNING**  
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

**DANGER**  
ELECTRICAL SHOCK HAZARD  
DISCONNECT POWER BEFORE SERVICING.

Wire Identification numbers for Bard use only.



Bard Mfg. Co.  
Bryan, Ohio

4109-304 B

460-60-3

Indoor Section

4 pin plug for Indoor Blower Motor

6 pin plug for Heater Package

5 pin plug for Indoor Blower Motor