



**Control Panel Section**

**CAPACITOR CHART**  
**MODEL CAPACITOR**  
**PH13422 5/370**

Transformer  
 Move Red Wire to 208V tap for 208V Operation

"A" Labeled wires connect if no options used.  
 Low Ambient Bypass (Optional)

**18 Heat Pump Control**

BLINK CODES

BLINK	FUNCTION
SLOW	NORMAL FUNCTION
FAST	ASCD TIMER ACTIVE
1	LPS FAILURE
2	HPS FAILURE SOFT LOCKOUT
3	DEFROST MODE ACTIVE
4	HPS FAILURE HARD LOCKOUT

SEN JMP SPEEDUP 90 60 30

	Factory	Field	Optional
High Voltage			
Low Voltage			

230/208-60-3 Diagram

**WARNING**  
 USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

**DANGER**  
 \*ELECTRICAL SHOCK HAZARD  
 \*DISCONNECT POWER BEFORE SERVICING.

99 Wire Identification numbers for Bard use only.



4110-204 A

230/208-60-3

**Indoor Section**

4 pin plug for Indoor Blower Motor

5 pin plug for Indoor Blower Motor

