



USE COPPER CONDUCTORS ONLY

460V 60 Hz 3-Ph

Model P36A4

Factory Wiring ———
Field Wiring - - - - -