



⚠ See alternate thermostat sheet.
Set heat anticipator at .40A.

USE COPPER OR ALUMINUM WIRE

Fused Disconnect Switch

230/208V 60 Hz 1-Ph

Single Package Air Conditioner
4 and 5 Ton
w/5Kw

Factory Wiring ———
Field Wiring - - - - -