

⚠ Capacitor provides off-cycle crankcase heat.

MODEL	CAPACITOR A	CAPACITOR B
PH31-1	35/370V	20/370V
PH36-2	40/370V	25/370V

See Installation Manual for 24V
Thermostat Wiring and Thermostat
Functions.

