


⚠ Capacitor provides off-cycle crankcase heat.

MODEL	CAPACITOR A	CAPACITOR B
PH31-1	35/370V	20/370V
PH36-2	40/370V	25/370V



See Installation Manual for 24V Thermostat Wiring and Thermostat Functions.

Fused Disconnect Switch

Factory Wiring ———  
Field Wiring - - - -

USE COPPER OR ALUMINUM WIRE

MODELS  
PH31-1, PH36-2  
Heat Pump