



- ⚠ 1 Capacitor provides off-cycle crankcase heat.
- ⚠ 2 Set heat anticipators at .40A
- ⚠ 3 Reroute jumper from X2-W2 to X2-E.

Single Package
Heat Pump
3-Ton
w/5Kw

Fused Disconnect Switch

USE COPPER OR ALUMINUM WIRE

230V 60 Hz 1-Ph

Factory Wiring ————
Field Wiring - - - - -