


- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ 2nd heat contactor operates only during emergency heat or compressor cut-off.



Fuse A - 60A Time Delay
 Fuse B - 60A Standard

Factory Wiring ———
 Field Wiring - - - -

MODELS	CAPACITOR "A"	CAPACITOR "B"
PH-31-1	35/370V	20/370V
PH-36-2	40/370V	25/370V

MODELS
 PH31-1, PH36-2
 Heat Pump
 w/15KW

USE COPPER OR ALUMINUM WIRE

230/208-60-1

4005-140