



See Installation Manual for 24V thermostat wiring and thermostat functions.

24V Terminal Block

Factory Wiring ———
Field Wiring - - - -

USE COPPER OR ALUMINUM WIRE

PH36-2 Heat Pump w/6,9Kw

Fused Disconnect Switch

230/208-60-3