


See Installation Manual for 24V thermostat wiring and thermostat functions.

24V Terminal Block



Factory Wiring _____
Field Wiring - - - - -

USE COPPER OR ALUMINUM WIRE

PH36-2 Heat Pump