



See Installation Manual for 24V thermostat wiring and thermostat functions.

24V Terminal Block

Reversing Valve Solenoid (24V)

Defrost Thermostat

Terminal Block

Compressor Contactor

Transformer

24V

High-Pressure Switch

Defrost Relay

Blower Relay

Outdoor Motor

5/370V Capacitor

480-240V Stepdown Transformer

Defrost Timer

Indoor Motor

5/370V Capacitor

Equip. Ground

Factory Wiring ———  
Field Wiring - - - -

PH36-2 Heat Pump

USE COPPER OR ALUMINUM WIRE

Fused Disconnect Switch

460-60-3

4005-310 F