


⚠ Capacitor provides off-cycle crankcase heat.



See Installation Manual for 24V
Thermostat Wiring and Thermostat
Functions.

24V
Terminal
Block

Emergency
Heat Relay

Outdoor
Motor

5/370V
Capacitor

Heater
Contactor

Electric Heater

Factory Wiring ———
Field Wiring - - - - -

USE COPPER OR
ALUMINUM WIRE

MODEL S
PH36-2
Heat Pump
w/10kw

4005-430

240/220-50-1