


See Installation Manual for 24V thermostat wiring and thermostat functions.



24V Terminal Block

Reversing Valve Solenoid (24V)

Defrost Thermostat

Terminal Block

LL3 LL2 LL1

Equip. Ground

Fused Disconnect Switch

230/208-60-3

USE COPPER OR ALUMINUM WIRE

Factory Wiring ———  
Field Wiring - - - -

PH36-2 Heat Pump 15 Kw

4005-800A