



- ⚠ Reroute jumper from X2-W2 to X2-E.
- ⚠ Set heat anticipators at .40A for W1 and W2.

Fused Disconnect Switch

USE COPPER OR ALUMINUM WIRE

Single Package Heat Pump 4 and 5 Ton w/5Kw

Factory Wiring ———
Field Wiring - - -