

USE COPPER CONDUCTORS ONLY

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet.
- ⚠ For 208V operation move this wire to 208V transformer tap.


Fused Disconnect Switch

230/200-60-1

MODELS
20WA1 & 24WA2

Factory Wiring ———
Field Wiring - - - - -

4007-814 B




USE COPPER CONDUCTORS ONLY

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet.

MODELS
20WA1 & 24WA2

Factory Wiring _____
Field Wiring - - - - -



USE COPPER CONDUCTORS ONLY

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet.

230/208-60-1

MODELS
20WA1 & 24WA2

Factory Wiring ———
Field Wiring - - - - -