



USE COPPER CONDUCTORS ONLY

- ⚠️ 1 Capacitor provides off-cycle crankcase heat.
- ⚠️ 2 See alternate thermostat sheet.
- ⚠️ For 208V operation move this wire to 208V transformer tap.

MODELS 20W1 & 24W2

Factory Wiring _____
Field Wiring - - - - -

4007-826A