


⚠ If there is an X1 and X2 terminal on Q674L1181, jumper them together and connect from C to either one.

⚠ For 208V operation move this wire to 208V transformer tap.

T872N1036/Q672F1299
OR
T874N1024/Q674F1261

T872R1164/Q672L1185
OR
T874R1129/Q674L1181



Fuse A - 50A T.D. for 42WH, 60A T.D. for 48WH5
Fuse B - 30A Standard
All fuses class K5

MODEL
42WH, 48WH5
HEAT PUMP
5 Kw

230/208-60-1

USE COPPER OR ALUMINUM WIRE

	FACTORY WIRING	FIELD WIRING
Low Voltage	_____	-----
High Voltage	_____	-----

4014-122A