



CHART A

	42WH	48WHS
Fuse A	50A TD	60A TD
Fuse B	60A STANDARD	

	FACTORY WIRING	FIELD WIRING
Low Voltage	————	-----
High Voltage	————	-----

ALL FUSES CLASS K5

⚠ If there is an X1 and X2 terminal ⚠ For 208V operation move this wire to 208V transformer tap. and connect from C to either one.

USE COPPER OR ALUMINUM WIRE