



- ⚠ THIS HEATER PACKAGE CONSISTS OF THE FOLLOWING:
 (1) BASIC HEATER PACKAGE
 (1) TERMINAL BLOCK (CAT. NO. ERB OR 11993)
 (1) LISTED GROUND TERMINAL 6-12 AL, 6-14 CU
- ⚠ REFER TO THE HEAT PACKAGE INSTRUCTIONS FOR PROPER INSTALLATION. SECOND HEATER CONTACTOR OPERATES ONLY DURING EMERGENCY HEAT OR COMPRESSOR CUTOFF.

USE COPPER OR ALUMINUM WIRE * 50HZ APPLICATION NOT U.L. LISTED

| | FACTORY WIRING | FIELD WIRING |
|--------------|----------------|--------------|
| Low Voltage | _____ | ----- |
| High Voltage | ————— | ----- |

240/208-60-3
240/220-50-3 *