



NOTE:
BARD 8403-066 CONTROLLER
MUST BE USED WITH THESE
UNITS. A THERMOSTAT WILL NOT WORK.

WARNING
USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT LEAST
75°C.

DANGER
ELECTRICAL SHOCK HAZARD
DISCONNECT POWER BEFORE
SERVICING.

<p>A Wires Connect if Option Not Used</p>	<p>99 Wire Identification numbers for Bard use only.</p>		
	Factory	Field	Optional
High Voltage	-----	-----	-----
Low Voltage	-----	-----	-----