



NOTE:
 BARD 8403-066 CONTROLLER
 MUST BE USED WITH THESE
 UNITS. A THERMOSTAT WILL NOT WORK.

<p>A</p> <p>Wires Connect if Option Not Used</p>	<p>99 Wire Identification numbers for Bard use only.</p>			<p>WARNING</p> <p>USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.</p>
	<p>High Voltage</p>	<p>Factory</p>	<p>Field</p>	
<p>Low Voltage</p>				

DANGER

ELECTRICAL SHOCK HAZARD
 DISCONNECT POWER BEFORE SERVICING.

4095-275 A